

Service
Service
Service



LC6231
LC7181

Garbo / Garbo Matchline

Service Manual

Contents

Page

1. Safety guidelines	1-1
2. Specifications	2-1
3. Warnings & Notes	3-1
4. Mechanical instructions	4-1
5. Block diagrams & Wiring diagram	5-1
6. Diagrams & PWB layouts	6-1
7. Directions for use	7-1
8. Optical alignments	8-1
9. Pars list	9-1



PHILIPS

1. Safety guidelines

IMPORTANT SAFETY NOTICE

Proper service and repair is important to the safe, reliable operation of all Philips Consumer Electronics Company** Equipment. The service procedures recommended by Philips and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It also is important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Philips could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, Philips has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by Philips must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

** Hereafter throughout this manual, Philips Consumer Electronics Company will be referred to as Philips.

WARNING

Critical components having special safety characteristics are identified with an \$ by the Ref. No. in the parts list and enclosed within a broken line* (where several critical components are grouped in one area) along with the safety symbol ⚠ on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from Philips. Philips assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.

* Broken Line — — — — —

2. Specifications

LC6231/LIC7181

2-1



	LC6231 (Garbo)	LC7181 (Garbo Matchline)
LCD	: 3x 0.65" true 16:9 high-temperature poly-silicon active matrix LCDs	
Resolution	: 854 x 480	XGA
Brightness	: 1000 ANSI lumens	1100 ANSI lumens
Contrast	: 400:1	500:1
Lamp	: 132W	132W
Average lifetime	: 6000 hours	3000 hours
Fan noise	: 27 dB	27 dB
Lens	: F/1.8 - 2.2 ; f = 28.4 - 34 mm; 1.2x Manual Zoom; Manual Focus. Projection distance 1,1 - 10 m (image diagonal 27.5" - 250")	
Input signals		
Video	: NTSC 3.58, 4.43 ; PAL B,G,D,H,I,N,M ; SECAM : S-video/S-VHS (Y/C) Component video input RGB-Y,YCbCr,YPbPr (480p,720p, 1080i)	
Computer	: PC and MAC compatible, Multi scan VGA-SXGA Horizontal scan rate: 15 - 108 kHz Vertical refresh rate: 50 - 120 Hz Bandwidth: 140 MHz	
Plug and play	: Display Data Channel DDC 1/2B	
Compatibility	: Microsoft® Windows® 95/98/ME/2000/XP compatible	
Input connectors		
Video	: Progressive component and component in R/Pr/Cr,G/Y,B/Pb/Cb (3x RCA) 1x S-Video (Y/C DIN) 1x CVBS Video (RCA)	
Computer	: 1x Data in (15p D-sub)	
Audio	: Audio L/R (2x RCA)	
Video	: 1x Stereo Audio (3.5 mm stereo jack)	
Data	: PS/2 (Mini Din), USB (type A)	
Mouse		
Features	: Picture in Picture (Matchline only) SmartSet™ automatic image quality optimisation SmartSave™ auto-standby mode to increase effective lamp usage Colour Tracking™ Digital Keystone correction, Digital Zoom and -Freeze Fitscreen 6W speaker	
Dimensions	: 235 x 335 x 108 mm (9.2" x 13.2" x 4.2") (WxDxH)	
Net weight	: 3.7 kg; 8.1 lbs	
Power consumption		
Operating voltage	: 100 - 240V, 50/60 Hz	
Operation	: 170W	
Standby	: 5W	
Temperature range		
Operational	: +5 to +35 °C (+41 to +95 °F)	
Storage	: -25 to +70 °C (-13 to +158 °F)	
EMC approbation	: Class B	
Package	: Pronto NEO Compact remote control Power cord VGA cable (2m) Audio/Video cable (2m) Scart/RCA Component adapter S-video cable (2m) Scart adapter (scart to RCA audio/video)* Lenscap Printed & CD-ROM User Guide (UK, D, F, E, PT, NL, I). Chinese version printed in region. Quick Setup Card (UK, D, F, E, PT, NL, I) Warranty card + envelopes Wallpaper CD-ROM	
Optional accessories	: 132W replacement lamp (LCA3116/00) 150W replacement lamp (LCA3118/00) Softbag (LCA 1120/00) Ceiling mount (LCA2211/00) VGA extension cable, 15 metres (LCA5300/00)	
Executions	LC6231/17 USA version LC6231/40 RoW version LC6231/45 UK version	LC7181/17 USA version LC7181/40 RoW version LC7181/45 UK version

* : depending on regional requirement

Image diagonal size		Projection distance			
		Tele zoom		Wide zoom	
[inch]	[metres]	[inch]	[metres]	[inch]	[metres]
40	1,0	75	1,9	62	1,6
60	1,5	114	2,9	93	2,4
70	1,8	133	3,4	1086	2,7
80	2,0	153	3,9	123	3,1
100	2,5	191	4,8	1552	3,9
150	3,8	286	7,3	233	5,9
200	5,1	381	9,7	310	7,9
250	6,4	477	12,8	388	9,8

3. Warnings & Notes

Warnings

1. Safety regulations require that the unit should be returned in its original condition and that components identical to the original components are used. The safety components are indicated by the symbol  or \$.
2. **ESD** 
All ICs and many other semiconductors are sensitive to electrostatic discharges (ESD). Careless handling during repair can drastically shorten the life. Make sure that during repair you are connected by a pulse band with resistance to the same potential as the earth of the unit. Keep components and tools also at this same potential.
3. When repairing a unit, always connect it to the mains voltage via an isolating transformer.
The lamp supply and the lamp housing are not mains isolated.
4. Be careful when taking measurements in the high-voltage section.
5. Never replace modules or other components while the unit is switched on.
6. When making settings, use plastic rather than metal tools.
This will prevent any short circuits and the danger of a circuit becoming unstable.
7. After repair the wiring should be fastened once more in the cable clamps for this purpose.
8. In order to prevent measuring errors, the heat sinks should not be used as reference points for measurements.
9. The Lamp house and the lamp get hot during operation.
Please ensure that they are cooled down before servicing.
10. The lighthouse (optical part) is extremely sensitive to dust.
This part should only be opened in a dust-free environment (class 100 according to the US federal standard 209).
11. Safety regulations require that safety goggles should be worn when servicing the unit in open view of the lamp.

Notes

1. The direct voltages and oscillograms should be measured with regard to earth (4), or hot earth (5) as this is called.
2. The semiconductors indicated in the circuit diagram and in the parts lists are completely interchangeable per position with the semiconductors in the unit, irrespective of the type indication on these semiconductors.

4. Mechanical instructions

4.1 Opening the cabinet

1. Remove the focus ring (A) and the zoom ring (B) by pulling them off (Fig. 1). Pulling off the zoom ring may require some force.



Fig. 1

CL 266450004_044.eps
230402

2. Pull off the front cover (C) by pulling it upward (Fig. 2). Pulling can best be done by using the opening of the lens.



Fig. 2

CL 266450004_046.eps
240402

3. Remove the 4 screws (D) holding the top cover (Fig. 3). If the 4 screws are removed, the top cover can be lifted off. Please be careful not to pull of the cable to the keyboard.



Fig. 3

CL 266450004_047.eps
240402

4. By putting the top cover to the side, the set can still be operated (Fig. 4). Be careful not to damage connector E. By pulling the flatfoil cable from connector E the topcover can be removed completely.



Fig. 4

CL 266450004_048.eps
240402

5. Remove the 6 screws “F” holding the top shield (Fig. 5). Then remove the 3 screws “G” and the 2 screws “H” (Fig. 6). Now the top shield can be removed.




Fig. 5 CL 266450004_049.eps 240402




Fig. 6 CL 266450004_050.eps 24402

2. Remove screw “K” and connectors “L” (Fig. 8). Nor the DRB (Drive Boards) can be removed.




Fig. 8 CL 266450004_052.eps 240402

3. Remove screw “L” (Fig. 9). Now the bottom shield can be removed.




Fig. 9 CL 266450004_053.eps 240402

4.2 Panel removal and service position

1. Remove screw “I” and connectors “J” (Fig. 7). Now the SSB (Small Signal Board) can be removed. The SSB is plugged onto the DRB (Drive Board).




Fig. 7 CL 266450004_051.eps 240402

- 4 Remove the 4 screws "M" (Fig. 10). Now the side cover can be removed.




Fig. 10

CL 266450004_054.eps
240402

5. Remove screws "N" (Fig. 11). After lifting the fan bracket, the filter holder and dust filter can be removed.




Fig. 11

CL 266450004_055.eps
240402

6. To operate the projector in this situation, connect the SSB and DRB together again, and connect the top-cover, LCD fan and dust filter switch to the SSB. Put some insulation under the SSB and DRB board. Now connect the LCD's to the DRB board by using extension cables (312243540400). (Fig. 12)

Do not operate the projector like this for a longer time, as the LCD's will be damaged when the cooling is not installed.




Fig. 12

CL 266450004_056.eps
230402

4.3 Engine and power supply removal

1. Remove the 3 screws "O" to remove the engine (Fig. 13).




Fig. 13

CL 266450004_057.eps
240402

2. Remove screws "P" to remove the Power supply (Fig. 13).




Fig. 13

CL 266450004_057.eps
240402

3. Remove the 2 screws "Q" to remove the lamp supply (Fig. 14).




Fig. 14

CL 266450004_058.eps
240402

4.4 Notes when mounting back together

1. Mounting position of PCS fan (See Fig. 15).




Fig. 15

CL 266450004_059.eps
140502

2. Mounting of air guide: First put the bottom pin into hole "R", and then click the top pin into hole "S". (Fig. 16).




Fig. 16

CL 266450004_060.eps
240402

3. Mounting position of lamp fan (See fig 17).




Fig. 17

CL 266450004_061.eps
240402

4. Mounting position of earth bracket. (See Fig. 18)




Fig. 18

CL 266450004_062.eps
230402


5. If after a repair the fan's go to high speed and the lamp switches off immediately, then check the filter door switch mounting.

5. Block diagrams & Wiring diagram

LC6231/LIC7181


5-1

BLOCK DIAGRAM




CL 26645004_026.eps
130502

Small Signal Electronics




CL 26645004_027.eps
130502

S2 DATA AD CONVERSION




CL 26645004_028.eps
130502

S3 VIDEO PROCESSING




CL 26645004_029.eps
1030502

S4 SCALER / FRAMEBUFFER / MICROPROCESSOR




CL 26645004_030.eps
130502

S5



S7

AUDIO PROCESSING



CL 26645004_031.eps
160402

The block diagram illustrates the hardware components and their interconnections. Key components include:


- 7108 PD1USBH11**: USB-to-UART bridge IC. It connects to the **UPSTREAM** port (pins 31, 32), a **+3V3** supply (pin 9), and the **I/O PROCESSOR** (pins 18, 19 for I^2C_2 to **S7**, and pin 17 for **INTH11** to **S7**). It also has pins 20 and 2 connected to ground.
- 7102 FXO-31 OSC**: Oscillator IC. It is powered by **+5V** (pin 4) and connected to the **7108** (pins 3, 6) and ground (pin 2).
- 7719 CY6264 RAM**: Random Access Memory. It is powered by **+5V** (pin 28) and connected to the **I/O PROCESSOR** (pins 30, 37) and ground (pin 14). It also has **AD0-AD7** and **AU0-AU7** data buses.
- 7737 74HCT573**: 8-bit D-type flip-flop. It is powered by **+5V** (pin 2) and connected to the **RAM** (pins 10, 15) and ground (pin 1).
- 7727 S87C654 I/O PROCESSOR**: The central microcontroller. It is powered by **+5V** (pin 38) and connected to the **RAM** (pins 30, 37), **7108** (pins 18, 19, 17), and **KEYBOARD** (pins 18, 20, 21-25, 42, 43). It also has control signals like **INTH11** to **S11**, **INTUSB**, **PS2**, **STANDBY**, and **STANDBY SENSE**.

The diagram illustrates the control system for the lamp and fans. It features a central microprocessor (μP) that manages the system. Key components and connections include:

- Temperature Sensor (Temp):** Provides input to the μP.
- Temp switch:** A manual switch that can override the temperature sensor's input to the μP.
- SSB (Supply Board):** Provides power to the system and includes a "standby sense" input to the μP.
- Standby Control:** The μP sends a "standby" signal to the SSB and a "standby sense" signal to the μP. The SSB also provides a "Lamp Lit" signal to the μP.
- Fan Control:** The μP sends a "fancontrol" signal to the Fan control unit. The Fan control unit manages the operation of the fans.
- Fans:** There are three fans: Fan Main, Fan LCD, and PCS fan. Each fan has a "fan stop" signal line connecting back to the μP.
- Dust Filter Switch:** A manual switch that can override the fan control signals to the fans.
- PCS fan stop:** A signal from the PCS fan back to the μP.
- DF(dustfilter)-det.:** A dust filter detection signal from the Fan control unit back to the μP.


The diagram shows the interconnections between these components, ensuring the system can operate in standby, normal, or emergency modes based on temperature, manual overrides, and fan status.

CL 26645004_033.eps
160103




26645004_034.eps
160402

POWER SUPPLY BOARD




26645004_042.eps
160402

DRIVE PROCESSING




26645004_097.eps
160103

D2 DRIVEBOARD MICROPROCESSOR




26645004_098.eps
160103


D3




D4




D5-6-7


26645004_100.eps
160103


D5-6-7

16645004_101.eps
130103





6. Diagrams & PWB layouts







2200	A7	3237	I5
2201	A7	3239	I4
2202	A7	3242-A	K13
2203	A8	3242-B	K13
2204	A8	3242-C	J13
2205	A9	3242-D	J13
2206	A9	3243	J6
2207	A10	3245	J6
2209	A10	3247	J4
2210	A11	3249-A	L13
2211	A11	3249-B	K13
2212	B7	3249-C	K13
2213	B7	3249-D	K13
2214	B7	3250	K6
2215	B8	3252	K6
2216	B12	3255-A	L13
2217	B16	3255-B	L13
2218	B17	3255-C	L13
2219	B18	3255-D	L13
2220	B19	3259-A	N13
2221	D16	3259-B	M13
2223	D17	3259-C	M13
2224	D18	3259-D	M13
2225	D19	5201	A19
2226	E5	5202	B19
2227	F6	5203	B16
2228	F5	5205	B19
2229	G6	5206	C16
2230	H5	5207	C19
2231	I6	5208	E3
2233	I6	5209	F4
2235	J4	5210	H4
2236	K4	7200	B17
2237	K4	7201	D17
2238	K4	7202	H9
2239	P12		
3200-A	C13		
3200-B	C13		
3200-C	C13		
3200-D	C13		
3205-A	D13		
3205-B	D13		
3205-C	D13		
3205-D	C13		
3210-A	E13		
3210-B	E13		
3210-C	D13		
3210-D	D13		
3214-A	F13		
3214-B	E13		
3214-C	E13		
3214-D	E13		
3218-A	G13		
3218-B	F13		
3218-C	F13		
3218-D	F13		
3221	F4		
3223-A	G13		
3223-B	G13		
3223-C	G13		
3223-D	G13		
3226	E4		
3229	H4		
3230-A	H13		
3230-B	H13		
3230-C	H13		
3230-D	I13		
3231-A	I13		
3231-B	I13		
3231-C	I13		
3231-D	H13		
3235	I5		
3236-A	J13		
3236-B	J13		
3236-C	J13		
3236-D	I13		









2500 B18
2502 B10
2504 B6
2506 C16
2510 F13
2514 F17
2516 F18
3500 B16
3502 B4
3505 C17
3506 C10
3507 C14
3508 C4
3509 B14
3510 D4
3511 D13
3512 D10
3513 E13
3514 E12
3516 J16
3526 K16
3530 M15
3531 K16
4501 L19
5510 B5
5511 A18
5968 A10
7501 C5
7502-A C10
7502-B D10
7502-C C13
7502-D D13
7503 B17
7510 I17
7511 I12



2600	B17	5620	K12
2602	B18	5622	K13
2604	C10	5624	K2
2606	C11	5626	L6
2608	D10	5628	L18
2610	D11	5630	L15
2612	D16	5632	L18
2614	F13	5634	M6
2616	I7	5636	M6
2618	J11	5638	N15
2620	J11	5640	N18
2622	J7	5642	N6
2624	J11	5644	N18
2626	K10	5646	O6
2628	K12	5648	K13
2630	L6	5650	K13
2632	L7	5967	L18
2634	L16	6600	I11
2636	L16	6602	K11
2638	L17	7600-A	E13
2640	L18	7600-B	D13
2642	M6	7600-C	F13
2644	M7	7600-D	B13
2646	N16	7602	D18
2648	N16	7616	E16
2650	N17	7618	F17
2652	N18	7620	F10
2654	N7	7622	F17
2656	P6	7626	K11
2658	P7	7628	L17
2660	N6	7630	N17
2662	L18		
3602	C13		
3604	D16		
3606	D16		
3608	D16		
3610	D8		
3612	E13		
3614	E15		
3616	E15		
3618	E16		
3620	E8		
3622	F16		
3624	F7		
3626	F17		
3628	F7		
3630	F17		
3636	F13		
3640	F7		
3641	E7		
3642	E8		
3662	I7		
3664	J11		
3666	K12		
3668	K12		
3670	N2		
3672	N2		
3674	N11		
3676	N11		
3678	N2		
3680	O2		
3682	O11		
3684	O11		
3686	P11		
3688	P11		
3690	F19		
3691	E12		
5600	B18		
5602	B14		
5604	K18		
5608	C11		
5610	D11		
5612	I6		
5614	J6		
5616	J6		
5618	J10		




1700	I12	7723-C	G13
2710	D18	7723-D	I7
2712	F18	7727	G10
2725	B11	7731	I17
2726	B7	7733	I17
2727	C17	7737	K5
2729	D4	7741-A	K12
2731	D11	7741-B	K13
2733	D11	7741-C	K15
2735	G13	7741-D	M15
2737	H8		
2739	H12		
2741	I16		
2743	I8		
2745	I12		
2747	J19		
2749	J5		
2751	K12		
2753	K14		
3701	A11		
3702	A8		
3703	B10		
3704	B7		
3705	B11		
3706	B7		
3707	E15		
3709	D17		
3711	F17		
3719	F15		
3721-A	F8		
3721-B	F8		
3721-C	F8		
3721-D	F9		
3727	F9		
3728-A	E13		
3728-B	E13		
3728-C	E13		
3728-D	F9		
3729	G9		
3730	G14		
3731	G15		
3732	H9		
3733	H16		
3734	H17		
3735	H9		
3736	H14		
3737	I16		
3739	I17		
3741	I18		
3742	I9		
3743	K14		
3745	J8		
3747	D18		
3749	F18		
3750	H9		
3991	H8		
3993	H12		
4701	G12		
5703	B16		
5705	D10		
5707	J18		
6700	B10		
6702	B6		
6704	D19		
6706	F19		
7711	B11		
7712	B8		
7715-A	E16		
7715-B	D16		
7715-C	C16		
7715-D	F16		
7715-E	G16		
7715-F	C18		
7719	F4		
7723-A	G12		
7723-B	H13		



A	2800	E11	5806	F19
	2802	E11	5808	F19
	2804	E10	5810	F3
	2806	E11	5812	F19
B	2808	E15	5814	G19
	2810	E16	6800	D10
	2818	E16	6802	J6
	2820	E10	6804	J6
C	2846	E3	6806	J6
	2848	F9	6808	J6
	2850	F2	6810	M7
	2852	F16	6812	M7
D	2854	F9	6814	N7
	2856	F9	6816	N7
	2858	F18	7802	G11
	2860	G16	7804	F17
E	2862	G9	7806	I17
	2864	G8	7808	K17
	2866	H11	7810-A	G2
	2868	H11	7810-B	I2
F	2870	H11	7810-C	J2
	2872	J7		
	2874	J7		
	2876	M6		
G	2878	M6		
	2880	G5		
	2881	G6		
	2882	H7		
H	2883	H8		
	3800	D15		
	3802	D15		
	3804	D16		
I	3806	D16		
	3808	E10		
	3810	E15		
	3812	E15		
J	3814	E16		
	3816	E16		
	3818	F18		
	3820	F18		
K	3822	F14		
	3824	F15		
	3826	F16		
	3842	F1		
L	3844	F13		
	3846	G16		
	3848	G13		
	3850	G3		
M	3852	G3		
	3854	G14		
	3856	H3		
	3858	H3		
N	3860	H7		
	3862	H8		
	3864	I11		
	3866	I17		
O	3868	I6		
	3870	J6		
	3872	J7		
	3874	J7		
P	3876	K17		
	3878	G5		
	3880	L7		
	3882	G5		
Q	3884	M7		
	3886	M6		
	3888	M6		
	3890	G5		
R	3891	G6		
	3892	H7		
	3893	H8		
	3894	D10		
S	3998	D3		
	3999	E3		
	5800	E10		
	5804	E2		


59


FAN CONTROL




2142	L19	5916	C12
2716	B14	5918	C7
2900	C19	5920	C12
2902	C4	5922	C7
2904	C10	5924	C12
2906	C6	5926	D7
2910	D6	5928	D12
2912	E6	5930	E7
2914	F4	5932	E7
2916	G6	5934	E4
2918	G6	5936	F7
2920	H14	5938	F7
2922	H16	5940	F7
2924	K4	5942	G7
2926	K6	5944	G7
2928	K6	5946	G14
2930	L16	5948	J4
2932	M9	5950	J7
2933	K19	5952	K7
2936	H9	5954	K7
2937	K9	5969	H8
2946	G5	5970	K9
3154	L18	6817	B16
3738	B15	7114	L19
3740	B15	7708	B14
3900	C10	7904-A	G10
3901	K18	7904-B	E10
3902	C5	7904-C	N9
3903	K18	7904-D	C10
3904	L18	7904-E	F10
3906	D4	7904-F	C9
3908	D6	7906	E17
3910	D5	7908	E4
3912	E5	7910	F5
3916	E5	7912	H14
3918	E6	7914	I17
3920	E11	7916	J10
3922	E4	7918	J5
3923	L18	7920	L15
3924	M18	7922	L10
3926	F6	7926	K19
3928	G5	7946	G4
3930	H4	7902	C5
3932	H5		
3936	H10		
3938	G6		
3940	G6		
3942	K5		
3944	G4		
3946	G4		
3954	K4		
3956	K6		
3958	K5		
3960	F15		
3962	G15		
3964	H15		
3972	H16		
3974	H14		
3976	I14		
3978	I14		
3980	J16		
3982	L15		
3984	L17		
3986	L16		
3988-A	D14		
3988-B	D14		
3988-C	D14		
3988-D	D14		
3990-A	D15		
3990-B	D15		
3990-C	D15		
3990-D	D16		
5900	C19		
5908	C7		
5912	C4		
5914	C7		

* RESERVED COMPONENTS









CL 26645004_024.eps
240402


1580 C6	2418 C4	3116 E2	3626 D3	3978 A2	6022 D1
1600 A6	2419 C4	3118 E2	3628 E2	3988 A2	6024 C1
1620 A2	2420 B3	3120 D1	3630 D3	3990 A3	6100 E1
1710 F2	2421 C4	3128 D1	3640 D2	3992 B4	6300 B1
1860 F3	2500 C5	3132 E1	3641 E2	4001 F2	6302 A1
1902 A5	2502 B5	3218 C3	3642 E2	4003 F2	6304 C1
1910 A1	2506 C5	3221 C1	3662 F3	4501 C5	6306 A1
1911 A5	2602 E3	3223 C3	3676 D4	4701 F2	6308 A1
1913 F1	2604 D2	3226 C1	3682 D4	5100 E1	6310 A1
1914 F1	2608 D2	3229 B1	3684 D4	5102 E1	6312 B1
1921 A3	2612 E2	3230 B3	3686 D4	5104 E2	6314 A1
1922 C5	2616 A2	3231 C3	3688 D4	5112 F1	6316 C1
2026 D1	2622 A2	3235 B1	3690 D3	5208 C1	6318 A1
2100 E1	2636 C4	3236 B3	3691 D2	5209 B1	6320 A1
2102 E1	2640 C4	3237 B1	3707 F1	5210 B1	6322 A1
2104 E1	2648 E3	3239 B1	3709 F1	5308 A4	6402 B5
2106 E2	2652 E3	3242 B3	3711 F1	5310 A3	6403 B5
2108 E2	2662 D4	3249 B3	3719 F1	5312 A3	6704 F1
2110 D1	2710 F1	3255 B3	3727 F3	5314 A3	6706 F1
2112 E1	2712 F1	3300 A4	3728 F2	5316 A3	6802 A1
2114 D1	2716 A3	3301 B1	3733 E2	5318 A3	6804 A1
2116 F1	2727 F1	3302 A1	3734 E2	5320 A3	6806 A1
2124 F1	2735 F2	3303 B1	3736 E2	5511 C5	6808 A1
2130 F1	2741 E2	3304 A1	3737 E2	5600 E3	6817 D1
2132 F1	2747 F2	3305 A1	3738 A3	5608 D2	7002 C1
2200 C3	2749 E3	3307 B1	3739 E2	5610 D2	7008 C1
2203 C2	2800 E5	3309 A1	3740 A3	5612 A2	7014 C1
2204 C2	2802 E5	3311 A1	3747 F1	5614 A2	7016 D1
2211 A2	2804 E4	3312 B4	3749 F1	5616 A6	7024 D1
2214 C2	2806 E5	3313 A1	3808 E5	5624 D5	7030 D1
2215 C2	2820 E4	3314 B4	3818 F4	5628 D4	7104 D1
2216 B1	2848 E5	3315 B1	3820 F4	5630 D4	7110 E1
2226 C1	2852 F4	3316 B4	3822 E4	5632 D5	7120 D1
2228 C1	2858 F4	3317 A1	3824 E4	5634 A6	7202 B2
2230 B1	2866 E5	3319 B1	3826 E4	5636 A6	7502 C5
2233 C1	2868 E5	3321 A4	3844 E4	5638 E3	7503 C5
2308 A4	2870 E5	3323 A4	3848 E4	5640 D3	7602 D3
2312 A4	2872 B1	3325 B4	3854 E4	5642 A6	7616 D3
2314 A4	2874 A1	3327 B4	3864 E5	5644 D3	7618 D2
2316 A4	2876 D1	3341 A5	3868 A1	5646 A6	7620 D2
2318 A4	2878 E1	3342 A5	3870 A1	5703 F1	7622 D3
2328 A3	2900 A2	3401 B5	3872 B1	5707 F2	7628 C4
2330 A3	2904 A6	3403 B5	3874 A1	5806 F3	7630 E3
2332 A3	2910 A2	3404 B4	3880 E1	5808 F3	7708 A3
2334 A3	2916 E6	3447 B4	3884 E1	5812 F4	7715 F1
2336 A3	2918 F1	3448 C4	3886 E1	5814 F4	7723 E2
2338 A3	2920 A1	3449 B5	3888 E1	5900 A3	7731 E2
2340 A3	2928 A5	3450 C4	3900 A5	5908 A2	7733 E2
2342 A3	2932 A5	3451 B4	3908 A2	5914 A2	7737 E3
2344 A3	2934 C5	3452 C4	3910 A1	5916 A6	7802 E5
2346 A3	2935 C4	3453 B4	3912 B6	5918 A1	7804 F4
2348 A3	2936 A2	3454 D3	3916 B6	5920 A5	7810 F5
2350 A4	2946 B6	3455 B5	3920 A5	5922 A1	7902 A1
2352 A4	3000 C1	3456 B5	3922 A6	5924 A5	7904 A5
2354 A4	3006 C1	3457 B5	3923 C1	5926 A1	7906 A2
2356 A4	3012 A1	3458 B5	3924 C1	5928 A5	7908 B6
2358 A4	3014 C1	3459 B5	3926 F1	5934 A6	7910 D6
2364 A4	3016 A1	3500 C5	3928 D6	5946 A2	7912 A2
2366 A4	3018 A1	3505 D5	3930 E6	5948 A5	7916 A2
2368 A4	3022 C1	3506 C5	3932 D6	5950 A5	7918 A5
2400 C4	3024 B1	3511 B5	3936 A2	5952 A5	7946 B6
2401 B4	3026 B1	3512 C5	3938 E6	5954 A5	
2402 C4	3030 C1	3513 B5	3940 E6	5956 E1	
2403 C4	3040 C1	3514 D5	3942 A5	5961 D1	
2405 B4	3054 D1	3531 B5	3944 B6	5967 D4	
2406 C3	3058 C1	3604 D3	3946 B6	5968 B5	
2407 B4	3064 C1	3606 D3	3954 A5	5969 A2	
2408 C4	3066 D1	3608 D3	3956 A5	6000 C1	
2411 C4	3072 D1	3610 E2	3958 A5	6002 C1	
2412 C4	3100 E1	3614 D3	3960 A2	6004 C1	
2413 C4	3101 D2	3616 D3	3962 A2	6006 C1	
2414 C4	3102 E2	3618 D3	3964 A2	6008 D1	
2415 B4	3104 E2	3620 E2	3972 A2	6010 D1	
2416 B4	3106 E1	3622 D2	3974 A2	6018 C1	
2417 C5	3108 E1	3624 D2	3976 A2	6020 D1	



1210 C6	2618 A5	3080 D6	3816 F3	5959 E6
1300 A7	2620 A5	3082 D6	3842 F3	5970 D5
1320 B7	2624 A5	3084 D6	3846 F3	6012 C5
1410 E3	2626 A4	3086 C6	3850 E3	6014 C5
1700 F5	2628 A5	3088 C6	3852 F3	6016 D5
1720 F7	2630 B1	3090 B6	3856 E2	6026 B6
1730 E7	2632 A1	3092 B6	3858 E2	6600 A5
1840 E7	2634 B2	3094 B6	3860 F3	6602 A5
2000 C6	2638 B2	3110 F5	3862 F3	6700 E5
2002 C6	2642 A1	3112 F5	3866 D2	6702 E6
2004 C6	2644 A1	3124 F6	3876 E2	6800 E3
2006 C6	2646 D4	3130 E6	3878 F2	6810 E6
2008 C6	2650 E4	3138 E5	3882 F2	6812 E6
2010 C6	2654 A2	3144 E6	3890 F2	6814 E6
2012 C6	2656 A1	3154 B6	3891 E2	6816 E6
2016 C6	2658 A1	3200 C5	3892 E2	7000 C6
2018 C6	2660 A1	3205 C5	3893 E2	7004 D5
2020 C6	2725 F5	3210 C4	3894 D3	7006 D5
2024 D5	2726 F4	3214 C4	3901 F3	7010 D5
2028 D6	2729 D5	3243 B6	3902 A6	7022 D6
2030 D6	2731 F4	3245 B6	3903 E3	7034 B6
2032 C6	2733 F4	3247 B5	3904 B6	7102 F6
2034 B6	2737 F4	3250 B6	3906 A6	7108 F6
2036 B6	2739 E5	3252 B6	3918 F6	7114 B6
2118 E5	2743 F4	3259 C5	3980 B6	7116 E6
2120 F6	2745 F5	3410 D3	3982 E2	7200 B5
2122 F6	2751 F4	3414 D3	3984 D2	7201 B5
2126 F2	2753 E4	3416 E3	3986 D2	7300 A4
2128 F2	2808 F4	3420 E3	3991 E4	7304 A3
2134 E6	2810 F4	3424 D4	3993 E5	7400 C3
2136 E5	2818 F3	3428 D4	3998 F2	7501 E2
2138 E6	2846 F2	3438 E3	3999 F2	7510 B1
2140 E5	2850 F3	3502 E2	4100 F6	7511 C1
2142 B6	2854 E2	3507 C2	5000 D6	7600 D4
2201 B4	2856 F2	3508 E2	5002 C6	7626 A5
2202 B4	2860 F3	3509 C2	5004 C5	7711 E5
2205 B5	2862 F2	3510 E2	5006 B6	7712 F3
2206 B6	2864 E2	3516 B2	5008 B6	7719 E4
2207 B6	2880 F2	3526 B1	5010 B6	7727 F5
2209 C5	2881 F2	3530 D2	5106 F6	7741 E4
2210 C5	2882 E2	3602 D4	5108 E5	7806 D2
2212 C4	2883 F2	3612 D4	5110 E6	7808 E2
2213 B4	2902 A6	3636 D4	5114 E5	7914 A5
2217 B5	2906 A5	3664 A4	5116 E5	7920 E2
2218 B5	2912 F6	3666 A5	5201 B5	7922 D5
2219 B5	2914 A2	3668 A5	5202 C4	7926 F3
2220 B5	2922 A5	3670 E3	5203 B5	
2221 C5	2924 A2	3672 E3	5205 B4	
2223 C5	2926 A2	3674 E3	5206 B5	
2224 C5	2930 E2	3678 E3	5207 B5	
2225 C5	2933 F3	3680 E3	5300 A4	
2227 C6	2937 D5	3701 F5	5302 B4	
2229 C6	3002 C4	3702 E4	5306 B4	
2231 B6	3004 C6	3703 F5	5510 E2	
2235 B5	3007 C6	3704 E4	5602 D5	
2236 B5	3008 C6	3705 F5	5604 B2	
2237 B5	3009 C6	3706 F4	5618 A5	
2238 B5	3020 C5	3721 F4	5620 A5	
2239 C5	3028 C5	3729 F5	5622 A5	
2300 A4	3032 C6	3730 F5	5626 A1	
2302 B5	3034 C6	3731 F5	5648 B4	
2304 A4	3036 C5	3732 F5	5650 B4	
2305 A4	3038 C5	3735 F5	5705 E5	
2306 A4	3042 C5	3741 F5	5800 E3	
2310 A2	3044 D5	3742 F5	5804 F3	
2404 B4	3046 D5	3743 E4	5810 E2	
2409 A2	3048 D5	3745 E5	5912 A6	
2504 E2	3056 D6	3750 E5	5930 F6	
2510 C2	3060 D6	3800 F3	5932 F6	
2514 B1	3062 D6	3802 E3	5936 F6	
2516 B1	3068 D5	3804 E3	5938 F6	
2600 E5	3070 D6	3806 F3	5940 F6	
2606 E5	3074 D6	3810 F3	5942 E6	
2610 E5	3076 D6	3812 F3	5944 E6	
2614 D5	3078 D6	3814 E3	5955 E6	





D2 MICROPROCESSOR




CL 26645004_089.eps
101202

A	1200	F9	3269	L4
	2200	D14	3270	L5
	2201	E14	5200	E8
	2202	E15	5201	E15
	2203	E8	5202	E18
B	2204	E8	5203	E14
	2205	E8	5204	G2
	2206	E18	5205	K15
	2207	F10	5206	M3
	2208	F10	5207	M14
C	2209	H2	5208	J2
	2210	I5	6200	C12
	2211	I5	6201	G4
	2212	L15	7200	D13
	2213	L13	7201	E11
D	2214	N3	7202	E11
	2215	J3	7203	F13
	3200	C13	7204	H15
	3201	D10	7205	I19
	3202	D10	7206	I7
E	3203	D11	7208	M14
	3204	D11	7209	L15
	3205-A	D2	7210-A	L16
	3205-B	D3	7210-B	L14
	3205-C	E3	7210-C	M13
F	3205-D	E3	7210-D	N6
	3206	D3	7210-E	O6
	3207	C13	7210-F	O6
	3210-A	D3	7211	M17
	3210-B	D3	7212	M17
G	3210-C	D4	7213-A	J3
	3210-D	D4	7213-B	K3
	3212-A	E19	7213-C	K3
	3212-B	E19	7213-D	L3
	3212-C	E20		
H	3212-D	E19		
	3216	E2		
	3219	E3		
	3220	E4		
	3221	E4		
I	3222-A	F5		
	3222-B	F5		
	3222-C	F5		
	3222-D	G5		
	3225	G4		
J	3228-A	G5		
	3228-B	G5		
	3228-C	G5		
	3228-D	G5		
	3233	G10		
K	3234	G10		
	3236	H4		
	3240	H2		
	3241	H3		
	3242	H4		
L	3243	H4		
	3244	J10		
	3246	J10		
	3248	J10		
	3249	K14		
M	3250	K16		
	3251	K10		
	3252	L10		
	3253	L10		
	3254	L10		
N	3255	L15		
	3256	K10		
	3257	M17		
	3260	H4		
	3261	G10		
O	3262	G10		
	3263	I3		
	3264	I3		
	3265	K4		
	3266	K5		
P	3267	L4		
	3268	L5		







D4 POWER SUPPLY/LCD CONTROL/PARAMETER EEPROM

2400	B8	7401-A	C8
2401	B4	7401-B	C11
2402	C9	7402	H8
2403	C12	7403	C9
2404	D6	7405	C3
2405	C4	7406	D6
2406	D2	7407	J2
2407	J1	7408	E3
2408	J3	7410	I6
2409	D3	7411	G6
2410	J5		
2411	J7		
2412	F2		
2413	F2		
2414	F2		
2415	G2		
2416	H4		
2417	H4		
2418	H4		
2419	J6		
2420	H5		
3400	D7		
3401	B9		
3402	E7		
3403	E8		
3404	C8		
3405	C11		
3406	C6		
3407	C4		
3408	C2		
3409	C7		
3410	D7		
3411	D7		
3412	E7		
3413	I7		
3414	E2		
3415	J7		
3416	E1		
3417	E1		
3418	C10		
3419	D10		
3420-A	G3		
3420-B	G3		
3420-D	G3		
3423-A	G3		
3423-B	G4		
3423-D	G4		
3423-E	F5		
3426	G4		
3427-A	G3		
3427-D	G3		
3430-A	H3		
3430-B	H3		
34300	CH3		
3430-D	F5		
3438-A	H3		
3438-C	H3		
3438-D	H3		
3441-A	H3		
3441-B	H4		
3441-C	H4		
3441-D	F5		
3442	H4		
3443	H3		
3444	C1		
3445	G6		
3446	G6		
3447	F8		
3448	G8		
5400	A7		
5401	B3		
5402	D2		
5403	G2		
6401	H8		
7400	E7		







1670	K11	2717	F8	7505	E4
1671	K13	2718	G3	7506-A	E17
1771	K11	2719	G3	7506-B	E16
1772	K13	2726	I9	7508-A	F16
1872	K11	2727	J17	7508-B	G17
1873	K13	2728	K15	7510-A	K16
2103	L17	2729	K16	7510-B	J16
2500	A10	2730	K9	7604	D12
2501	A11	2731	L16	7605	E4
2502	E18	2732	L17	7606-A	E17
2503	A12	3501	B13	7606-B	E16
2504	A12	3502	N12	7608-A	F16
2505	A13	3506	D2	7608-B	G17
2506	A13	3507	E16	7610-A	K16
2507	B3	3508	E2	7610-B	J16
2508	B4	3509	E16	7704	D12
2509	B5	3510	E17	7705	E4
2510	B6	3511	F16	7706-A	E17
2511	B6	3512	F17	7706-B	E16
2512	B6	3513	G16	7708-A	F16
2513	E14	3514	J17	7708-B	G17
2514	E14	3515	J17	7710-A	K16
2515	E14	3516	K17	7710-B	J16
2516	E14	3517	L17		
2517	F3	3601	B13		
2518	G3	3602	N12		
2519	G3	3606	D2		
2526	I9	3607	E16		
2527	J17	3608	E2		
2528	K15	3609	E16		
2529	K16	3610	E17		
2530	K9	3611	F16		
2531	L16	3612	F17		
2600	A10	3613	G16		
2601	A11	3614	J17		
2602	E18	3615	J17		
2603	A12	3616	K17		
2604	A12	3617	L17		
2605	A13	3701	B13		
2606	A13	3702	N12		
2607	B3	3706	D2		
2608	B4	3707	E16		
2609	B5	3708	E2		
2610	B6	3709	E16		
2611	B6	3710	E17		
2612	B6	3711	F16		
2613	E14	3712	F17		
2614	E14	3713	G16		
2615	E14	3714	J17		
2616	E14	3715	J17		
2617	F3	3716	K17		
2618	G3	3717	L17		
2619	G3	5500	A10		
2626	I9	5501	D16		
2627	J17	5502	A14		
2628	K15	5503	B6		
2629	K16	5504	B3		
2630	K9	5507	I15		
2631	L16	5508	I9		
2632	L17	5509	K8		
2700	A10	5600	A10		
2701	A11	5601	D16		
2702	E18	5602	A14		
2703	A12	5603	B6		
2704	A12	5604	B3		
2705	A13	5607	I15		
2706	A13	5608	I9		
2707	B3	5609	K8		
2708	B4	5700	A10		
2709	B5	5701	D16		
2710	B6	5702	A14		
2711	B6	5703	B6		
2712	B6	5704	B3		
2718	E14	5707	I15		
2714	E14	5708	I9		
2715	E14	5709	K8		
2716	E14	7504	D12		


6 LCD DRIVE




D 7 LCD DRIVE



1670	H11
1671	G13
2700	A10
2701	A11
2702	D18
2703	A12
2704	A13
2705	A13
2706	A13
2707	B3
2708	B4
2709	B5
2710	B6
2711	B6
2712	B6
2713	E14
2714	E14
2715	E14
2716	E15
2717	F3
2718	G3
2719	G3
2726	I9
2727	J17
2728	J15
2729	J16
2730	K9
2731	L16
2732	L17
3701	B13
3702	N13
3706	D2
3707	D17
3708	E2
3709	E16
3710	E18
3711	F16
3712	F18
3713	G17
3714	J17
3715	J17
3716	K17
3717	L17
5700	A10
5701	D16
5702	A14
5703	A6
5704	B3
5707	I15
5708	I9
5709	K9
7704	B11
7705	B4
7706-A	E17
7706-B	E18
7708-A	F17
7708-B	G18
7710-A	K17
7710-B	I17




2200	F2	3207	E3	3712	D3
2201	E1	3248	E3	3713	D4
2203	E2	3249	E2	5203	D1
2212	E2	3250	E2	5205	E2
2213	E2	3255	E2	5206	F2
2214	F2	3256	E1	5207	E2
2215	F1	3257	E1	5208	F1
2301	B1	3265	D2	5303	D2
2304	C2	3266	D2	5501	C4
2306	A3	3267	D2	5504	A3
2307	A2	3268	D2	5508	B3
2309	C2	3269	D2	5509	B4
2310	C1	3270	D2	5601	C3
2312	A3	3304	B1	5603	D2
2313	D2	3309	B1	5604	C1
2407	F3	3310	C2	5701	C4
2408	F3	3311	C2	5703	E3
2416	E3	3315	C2	5704	F4
2417	E3	3319	C2	5708	E3
2418	D3	3320	C3	6200	F2
2420	D3	3321	C3	6401	E2
2502	C4	3330	B3	7200	F2
2506	C4	3340	C1	7201	F2
2507	A3	3341	A3	7202	F2
2508	A3	3342	C1	7203	E1
2509	A3	3349	B3	7208	E2
2510	B3	3354	B3	7209	E2
2511	A4	3357	B1	7210	E2
2513	C4	3362	C2	7211	E2
2514	C4	3367	B3	7212	E2
2515	C4	3375	B3	7213	E1
2517	A3	3379	D2	7300	B2
2518	A4	3380	D2	7301	D2
2519	A3	3381	D2	7402	E3
2526	B3	3382	D2	7403	A3
2530	B4	3383	D2	7407	F3
2602	C3	3384	D2	7411	D2
2606	D3	3401	A4	7505	A3
2607	C1	3406	A4	7506	C4
2608	C1	3416	E2	7508	C4
2609	C1	3417	E2	7605	C2
2610	D2	3418	A4	7606	C3
2611	C2	3419	A4	7608	C3
2612	D2	3438	D2	7705	E3
2613	C3	3441	E2	7706	D3
2614	C3	3445	E2	7708	D4
2615	C3	3446	E2		
2617	C1	3448	E3		
2619	D2	3506	A3		
2702	D4	3507	C4		
2706	D4	3508	A3		
2707	F4	3509	C4		
2708	F4	3510	C3		
2709	E4	3511	C4		
2710	E3	3512	C3		
2711	E3	3513	C4		
2712	E3	3606	C1		
2713	D4	3607	C3		
2714	D4	3608	C1		
2715	D4	3609	C3		
2716	D4	3610	C3		
2717	E4	3611	C3		
2718	E3	3612	C3		
2719	E3	3613	C3		
2726	E3	3706	F4		
3200	F1	3707	D4		
3201	F2	3708	F4		
3202	F2	3709	D4		
3203	F1	3710	D3		
3204	F2	3711	D4		





CL 26645004_096.eps
131202

1101	A3	2705	D1	3442	E2
1200	F4	2727	E2	3443	E2
1670	E1	2728	E2	3444	F2
1671	E1	2729	E2	3447	F3
1771	C3	2730	E1	3501	C1
1772	C3	2731	E1	3502	B1
1872	B1	2732	E1	3514	A1
1873	B1	3205	F2	3515	B1
2100	A2	3206	F2	3516	A2
2101	A1	3210	E2	3517	B2
2103	B2	3212	E4	3601	C2
2202	D4	3216	F2	3602	C3
2204	E3	3219	F2	3614	C4
2205	F3	3220	E2	3615	C3
2206	E4	3221	E2	3616	D3
2207	F4	3222	F3	3617	D3
2208	F3	3225	F2	3701	D1
2209	F3	3228	F2	3702	E2
2210	E2	3233	F3	3714	E2
2211	E2	3234	F3	3715	E2
2300	A4	3236	F3	3716	E1
2302	B3	3240	E2	3717	E1
2303	B3	3241	E2	5100	A2
2305	B2	3242	E2	5101	A2
2308	B3	3243	E2	5200	E2
2311	B2	3244	E2	5201	D4
2400	A1	3246	E2	5202	E4
2401	F2	3251	E3	5204	F3
2402	A2	3252	E3	5300	A2
2403	A2	3253	E3	5301	B3
2404	A1	3254	E3	5302	B3
2405	F1	3260	F3	5400	A1
2406	F1	3261	F3	5401	F2
2409	E3	3262	F3	5402	E3
2410	B3	3263	F3	5403	E2
2411	B3	3264	F3	5500	C1
2412	D3	3300	B3	5502	C1
2413	E3	3302	B4	5503	A2
2414	E3	3325	B2	5507	B1
2415	D2	3329	B3	5600	D1
2419	B3	3332	B3	5602	D2
2500	C1	3343	C3	5607	C3
2501	C1	3347	C3	5608	D3
2503	C1	3348	C3	5609	C3
2504	C1	3358	B4	5700	C1
2505	C1	3363	C3	5702	D1
2512	A1	3368	C2	5707	E2
2516	C1	3370	A3	5709	E1
2527	A1	3376	A3	6201	F3
2528	A1	3377	A3	7204	D4
2529	B1	3378	A3	7205	E4
2531	A2	3400	F2	7206	E3
2600	D1	3402	F2	7400	F2
2601	C1	3403	F3	7401	A2
2603	C2	3404	A2	7405	F2
2604	C2	3405	A1	7406	A1
2605	D2	3407	F1	7408	D3
2616	C2	3408	F1	7410	B3
2618	C3	3409	A1	7504	C1
2626	D3	3410	A1	7510	A1
2627	C3	3411	A1	7604	C2
2628	C4	3412	A1	7610	C3
2629	C3	3413	B3	7704	D1
2630	C3	3414	E3	7710	E2
2631	D4	3415	B3		
2632	D3	3420	D3		
2700	D1	3423	D2		
2701	C1	3426	E3		
2703	D1	3427	D2		
2704	D1	3430	D2		

1006	E3	1020	B1	3001	A2	1001	D3	3013	B8	3018	C10	6002	B10	7004	A5	3008	B5	3012	B10
1007	E2	1021	A1	3002	A10	1002	D2	3014	B8	5000	A2	6003	A8	7005	B9	7008	C9	7006	B9
1008	E3	2000	A3	3003	B2	1003	D3	3015	B10	5001	B5	7000	A2	3005	A8	3009	B8	7007	C9
1009	E3	2001	B5	3004	C2	1004	D3	3016	B8	6000	C10	7001	A9	3006	A10	3010	B8		
1010	E2	3000	A2	1000	D2	1005	E2	3017	C10	6001	A10	7003	B9	3007	B5	3011	B8		







Philips Home Cinema Projector

Garbo Matchline



English User guide

7. Directions for use

LC6231/LIC7181

7-1

1. Introduction

Congratulations on your purchase of one of the most sophisticated and reliable products on the market today. We are sure that, used properly, it will bring you years of enjoyment. You will want to keep this manual handy as it is a convenient source of information about your projector. For your own protection and prolonged operation of your projector, please read the enclosed Safety Sheet.

Packaging contents

Please confirm that the following items are packed in the projector box. They are provided to help you use or set up your projector.


Projector Lenscap - 3122 434 21542	Remote control + batteries 3 x AA, 1.5 V - 3104 207 13810	Audio/Video RCA Cable 4822 320 12280
VGA Cable 3122 438 75110	S-Video cable 3122 438 75140	Mains Lead Europe: 4822 321 11399 USA: 4822 321 11294 UK: 4822 321 11431
Printed User Guide 3103 435 90070	Cd-rom (with Projection Assistant, Warranty card, User Guide, Data sheet and more.) 3103 438 70060	Quick set up Card and Safety Sheet 3103 435 90060
Scart/RCA Audio Video adapter (not for USA version) 2422 033 00345	Scart/RCA component Video adapter (not for USA version) 3122 438 71170	

Optional accessories

- LCA 1120/00 - Soft bag - 8670 911 20009
- LCA 3116/00 - 132 W replacement lamp - 8670 931 16009
- LCA 2211/00 - Ceiling mount - 8670 922 11009
- LCA 5310/00 - Monitor Y-cable - 8670 953 10009
- LCA 5300/00 - VGA extension cable (15 m) - 8670 953 00009

Note

For further information on parts and accessories, please contact the dealer from which you purchased your Philips projector.



- A (audio)/V (video)

Mute ①

To mute the sound of the projector and to mute the picture.
- Source** ②

To select the current projection source (Video, S-Video, Component, RGBS, Computer).
The button toggles between the five signals.
- / +** ③

To adjust the volume.
- Menu** ④

To activate and deactivate the menu.
- OK** ⑤

To confirm actions in the menu when the menu is on screen.
- Standby/Standby indicator** ⑥

To switch the projector in or out of the Power/Standby mode.
The Standby indicator (text on button/ring around button):
 - lights up orange when the projector is warming up;
 - lights up red when the projector is in Power/Sandby mode;
 - lights up green as when the projector is operating;
 - slowly blinks orange when the projector is cooling down.
- Temperature indicator** ⑦

- Lights up red in case of temperature error.
 - Flashes in case of fan error.
- Lamp indicator** ⑧


- Lights up green when the lamp is on.
 - Lights up orange when lamp life has almost expired.
 - Lights up red when lamp life has expired.
 - Fast blinks red when lamp start has failed.
- IR sensor** ⑨

To receive the signals from the remote control.
- Cursor Control** ⑩

When the menu is active the Cursor Control controls the menu cursor to navigate through the OSD menu. The cursor control works with up/down and left/right button operation.
- Focus ring** ⑪

To adjust the focus of the projected image.
- Zoom ring** ⑫

To adjust the size of the projected image.



- Height/Level adjuster** ⑬


To adjust the vertical angle of the projector.
- Dust filter** ⑭

To connect the projector to the mains.
- Mains inlet socket** ⑮

To insert an optional locking device (Kensington lock).
- Lock slit** ⑯
- Lamp compartment** ⑰

2. Functional overview

Remote control >



The ProntoNEO remote control supplied is an intelligent remote control that can be used for virtually all audio and video devices that understand infrared (IR) signals. In this chapter we will describe the remote control buttons needed for operating your Garbo Matchline projector. For further use of the remote control see the information in the ProntoNEO user manual supplied. The remote control operates with soft and hard buttons. Soft buttons are the buttons you can tap on the LCD touch screen. Hard buttons are the buttons located below and on the left side of the LCD touch screen. To activate the remote control, press any button or gently tap the touch screen with your finger or a soft object. The display will then light up.

Note

Before operating your projector via the remote control, first, press the Device selection button and select Projector on the Device Overview page.

Hard buttons


- +/- (Page up/down) ①**
To select a next/previous soft button page.
- A (Audio)/N (Video) Mute ②**
To mute the sound of the projector and to mute the picture.
- Vol(ume) + ③**
To adjust the volume.
- OK ④**
To confirm actions in the menu when the menu is on screen.
- Mute ⑤**
To mute the sound of the projector.

Cursor Control ⑥ When the menu is active the Cursor Control controls the menu cursor to navigate through the OSD menu. The cursor control works with up/down and left/right button operation.

- Menu ⑦** To activate and de-activate the menu.
- Device selection button ⑧** To select the Device Overview page.

2. Functional overview

Remote control <



Soft buttons

- To switch the projector in or out of the Power/Standby mode.
- To select the current projection source (Video, S-Video, Component, RGBS, Computer).
- The button toggles between the live signals.

To capture a (moving) picture. The button toggles between the Freeze mode and the display situation.

To correct picture distortion of the vertical keystone type by digital scaling.

To project a Video or S-Video picture in the currently projected computer picture.

To select one of the six available picture format options (wide screen, super zoom 4:3, 4:3, movie expand 14:9, movie expand 16:9, 16:9 subtitles).

To manipulate the mouse cursor on the connected computer as long as the menu is not active. The cursor control works with up/down and left/right button operation. The Cursor Control can only function as a mouse cursor when projector and computer are connected via the USB or PS/2 connectors. Windows 98, Windows ME, Windows 2000 or Windows XP should be installed on the computer when you make the USB connection.

Function as Left and Right mouse buttons of your pc when USB or PS/2 connection has been made.

Standby/On ①

Source ②

D(igital)-Freeze ③

Keystone Correction ④


PIP (Picture In Picture) ⑤





Picture format ⑥


Cursor Control ⑦





Note





Mouse Left/Right ⑧


2. Functional overview		Connections <
		 <p>Video source connections Input sockets to connect to DVD- and HDTV-video equipment. These sockets can be connected to the following output sockets: RGB-Y, YCbCr, YPbPr (480p, 720p, 1080 i).</p> <p>Video ② Input socket to connect to the Video out socket of a video recorder, Laser Disc player, video camera, DVD player, or TV with AV output socket. This socket can be connected to CVBS output sockets.</p> <p>Audio L/R ③ Input sockets to connect to the Audio out sockets of a video recorder, laser disc player, video camera or TV with AV output socket.</p> <p>S-Video ④ Input socket to connect to the S-Video out socket of a S-VHS video recorder, a VCR, Laser Disc player, DVD player, video camera or TV with AV output socket. This socket can be connected to a S-Video/S-VHS (Y/C) output socket.</p> <p>Data source connections Input socket to connect to the Data out terminal of a computer.</p> <p>Computer ⑤ Input socket to connect to the Audio out terminal of a computer.</p> <p>Audio in Computer ⑥ In-/Output socket to connect a PC or Apple Macintosh computer equipped with a USB downlink connection. When USB connection is used the mouse cursor on the connected computer can be controlled via the projector remote control. Make sure Windows 98, Windows ME, Windows 2000 or Windows XP is installed on the computer.</p> <p>PS/2 ⑧ In-/Output socket to connect a PC or Apple Macintosh computer equipped with a PS/2 connection. When PS/2 connection is used the mouse cursor on the connected computer can be controlled via the projector remote control.</p>
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 9</p>





3. Set up		>
		<div> <div>  <p>Front projection</p> </div> <div>  <p>Ceiling front projection</p> </div> <div>  <p>Rear projection</p> </div> <div>  <p>Ceiling rear projection</p> </div> </div> <ul style="list-style-type: none"> Place the projector on a stable, level surface, out of direct sunlight and away from sources of excessive dust, dirt, heat, water, moisture, vibration and strong magnetic fields. Allow sufficient cooling of the product by keeping all air inlets and outlets clear from obstructions. Position the projector in such way that the viewers cannot watch into the projector light beam. Choose a screen size suitable for the number of viewers and the size of the room. Picture quality is best when you sit directly in front of the projector screen. The projector can be used for both front projection, rear projection and ceiling projection applications. As default factory setting, the projector has been set up for front projection. You can change to rear or ceiling projection via the 'Mirror' function in the 'Picture' menu. <ol style="list-style-type: none"> Insert the mains lead into the projectors Mains inlet socket and connect it to the wall socket. The Standby indicator lights up red, the projector is now in the Power/Standby mode. Remove the lens cap. Press any button on projector or remote control to switch on the projector. The Standby indicator lights up orange. When the projection lamp is on, the Standby indicator lights up green and the start-up screen appears for several seconds.
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>


Positioning the projector and screen		
		<p>Switching on the projector</p>  <p>PHILIPS Home Cinema Projectors</p> <p>Warning If the projector is switched off, you have to wait 1 minute before you can switch on the projector again.</p> <p>Press standby key again to confirm. Press OK key to remove this warning.</p> <p>Notes</p>
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>





3. Set up		>
		<div> <div>  <p>Front projection</p> </div> <div>  <p>Ceiling front projection</p> </div> <div>  <p>Rear projection</p> </div> <div>  <p>Ceiling rear projection</p> </div> </div> <ul style="list-style-type: none"> Place the projector on a stable, level surface, out of direct sunlight and away from sources of excessive dust, dirt, heat, water, moisture, vibration and strong magnetic fields. Allow sufficient cooling of the product by keeping all air inlets and outlets clear from obstructions. Position the projector in such way that the viewers cannot watch into the projector light beam. Choose a screen size suitable for the number of viewers and the size of the room. Picture quality is best when you sit directly in front of the projector screen. The projector can be used for both front projection, rear projection and ceiling projection applications. As default factory setting, the projector has been set up for front projection. You can change to rear or ceiling projection via the 'Mirror' function in the 'Picture' menu. <ol style="list-style-type: none"> Insert the mains lead into the projectors Mains inlet socket and connect it to the wall socket. The Standby indicator lights up red, the projector is now in the Power/Standby mode. Remove the lens cap. Press any button on projector or remote control to switch on the projector. The Standby indicator lights up orange. When the projection lamp is on, the Standby indicator lights up green and the start-up screen appears for several seconds.
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>


3. Set up		>
		<div> <div>  <p>Front projection</p> </div> <div>  <p>Ceiling front projection</p> </div> <div>  <p>Rear projection</p> </div> <div>  <p>Ceiling rear projection</p> </div> </div> <ul style="list-style-type: none"> Place the projector on a stable, level surface, out of direct sunlight and away from sources of excessive dust, dirt, heat, water, moisture, vibration and strong magnetic fields. Allow sufficient cooling of the product by keeping all air inlets and outlets clear from obstructions. Position the projector in such way that the viewers cannot watch into the projector light beam. Choose a screen size suitable for the number of viewers and the size of the room. Picture quality is best when you sit directly in front of the projector screen. The projector can be used for both front projection, rear projection and ceiling projection applications. As default factory setting, the projector has been set up for front projection. You can change to rear or ceiling projection via the 'Mirror' function in the 'Picture' menu. <ol style="list-style-type: none"> Insert the mains lead into the projectors Mains inlet socket and connect it to the wall socket. The Standby indicator lights up red, the projector is now in the Power/Standby mode. Remove the lens cap. Press any button on projector or remote control to switch on the projector. The Standby indicator lights up orange. When the projection lamp is on, the Standby indicator lights up green and the start-up screen appears for several seconds.
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>

Positioning the projector and screen		
		<p>Switching on the projector</p>  <p>PHILIPS Home Cinema Projectors</p> <p>Warning If the projector is switched off, you have to wait 1 minute before you can switch on the projector again.</p> <p>Press standby key again to confirm. Press OK key to remove this warning.</p> <p>Notes</p>
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>

3. Set up		>
		<div> <div>  <p>Front projection</p> </div> <div>  <p>Ceiling front projection</p> </div> <div>  <p>Rear projection</p> </div> <div>  <p>Ceiling rear projection</p> </div> </div> <ul style="list-style-type: none"> Place the projector on a stable, level surface, out of direct sunlight and away from sources of excessive dust, dirt, heat, water, moisture, vibration and strong magnetic fields. Allow sufficient cooling of the product by keeping all air inlets and outlets clear from obstructions. Position the projector in such way that the viewers cannot watch into the projector light beam. Choose a screen size suitable for the number of viewers and the size of the room. Picture quality is best when you sit directly in front of the projector screen. The projector can be used for both front projection, rear projection and ceiling projection applications. As default factory setting, the projector has been set up for front projection. You can change to rear or ceiling projection via the 'Mirror' function in the 'Picture' menu. <ol style="list-style-type: none"> Insert the mains lead into the projectors Mains inlet socket and connect it to the wall socket. The Standby indicator lights up red, the projector is now in the Power/Standby mode. Remove the lens cap. Press any button on projector or remote control to switch on the projector. The Standby indicator lights up orange. When the projection lamp is on, the Standby indicator lights up green and the start-up screen appears for several seconds.
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>

Positioning the projector and screen		
		<p>Switching on the projector</p>  <p>PHILIPS Home Cinema Projectors</p> <p>Warning If the projector is switched off, you have to wait 1 minute before you can switch on the projector again.</p> <p>Press standby key again to confirm. Press OK key to remove this warning.</p> <p>Notes</p>
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>

3. Set up		>
		<div> <div>  <p>Front projection</p> </div> <div>  <p>Ceiling front projection</p> </div> <div>  <p>Rear projection</p> </div> <div>  <p>Ceiling rear projection</p> </div> </div> <ul style="list-style-type: none"> Place the projector on a stable, level surface, out of direct sunlight and away from sources of excessive dust, dirt, heat, water, moisture, vibration and strong magnetic fields. Allow sufficient cooling of the product by keeping all air inlets and outlets clear from obstructions. Position the projector in such way that the viewers cannot watch into the projector light beam. Choose a screen size suitable for the number of viewers and the size of the room. Picture quality is best when you sit directly in front of the projector screen. The projector can be used for both front projection, rear projection and ceiling projection applications. As default factory setting, the projector has been set up for front projection. You can change to rear or ceiling projection via the 'Mirror' function in the 'Picture' menu. <ol style="list-style-type: none"> Insert the mains lead into the projectors Mains inlet socket and connect it to the wall socket. The Standby indicator lights up red, the projector is now in the Power/Standby mode. Remove the lens cap. Press any button on projector or remote control to switch on the projector. The Standby indicator lights up orange. When the projection lamp is on, the Standby indicator lights up green and the start-up screen appears for several seconds.
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>

Positioning the projector and screen		
		<p>Switching on the projector</p>  <p>PHILIPS Home Cinema Projectors</p> <p>Warning If the projector is switched off, you have to wait 1 minute before you can switch on the projector again.</p> <p>Press standby key again to confirm. Press OK key to remove this warning.</p> <p>Notes</p>
		<p>Philips Home Cinema Projector</p> <p>English User guide Garbo Matchline 10</p>


3. Set up

Adjusting the focus and size of the image



- Use the Zoom ring to adjust the size of the image.
- Use the Focus ring to adjust the focus of the image.

Adjusting the vertical angle of the projector



- To raise:**
- Keep knob A pressed and lift to raise the projector.
 - The Height/Level Adjuster B will come out.
- To lower:**
- Keep knob A pressed and gently lower the projector.
 - Use the Focus Ring and Zoom Ring to readjust the focus and size of the image.

Keystone correction



If projector and screen are not properly placed, the picture will be distorted, producing a keystone image (picture top width larger than picture bottom width or vice versa). When a keystone image occurs the image ratio (4:3, 16:9) will still be guaranteed. This is especially important when the projector is being used together with an 'intelligent' whiteboard'. 'Keystone correction' allows you to correct picture distortion of the vertical keystone type by internal scaling.

- Use the Keystone button ∇ to widen the image.
 - Use the Keystone button Δ to narrow the image.
- This correction function also is accessible through the 'Keystone Correction' option in the 'Settings' menu of the On Screen Display (OSD) menu.

Moving/transporting the projector

- Preparation**
- 1 Press the Standby button twice to put the projector in Power/Standby.
 - The Standby indicator starts blinking orange.
 - 2 Wait until the cooling fan has stopped (about 3 minutes after the projector has been put in Standby) and disconnect the mains lead and all other cables.
 - 3 Put the lens cap back in place to prevent dust, dirt or other contamination from harming or damaging the front of the projector lens when moving the projector.
- Never place the projector on the side where the connections are located.*

Note

Moving/transporting the projector

The projector contains many glass and precision parts. If you need to transport the projector, please follow these packing instructions to prevent accidental damage to the projector.

- When you are hand-carrying the projector, be sure to use a carrying case like the optional softbag.
- When shipping the projector, use the original packaging material if possible. If you do not have the original packaging, use equivalent materials, placing plenty of cushioning around the projector.
- When transporting the projector as freight or checked luggage, first put it in a carrying case, then pack it in a firm box, using cushioning around the case.

Inserting the batteries in the remote control



- 1 Push and slide the lid in the direction of the arrow.
- 2 Install two 'AAA' batteries as indicated inside the battery compartment.
- 3 Replace the lid and snap it into place.

The maximum range of the remote control is approximately 15 m (\pm 50 feet).

4. Installation

General information

Video input

The projector accepts the input signal of all major video formats, including NTSC 3.58, 4.43, PAL, B, G, D, H, I, N, M and SECAM signals. The projector will recognize these standards and adapt to them automatically. With the 'Picture Format' feature you can select one of six picture format options: wide screen, super zoom 4:3, 4:3, movie expand 14:9, movie expand 16:9, 16:9 subtitles.

Computer input

The computer input is suitable for both Apple Macintosh computers (Power Book and Power Mac) as well as for IBM compatible PCs. The projector is Microsoft (R), Windows (R) 95/98/ME/2000/XP compatible and accepts input signals from all computers that meet following specifications:

- Multi scan VGA-SXGA
- Horizontal scan rate: 15-108 kHz
- Vertical refresh rate: 50-120 Hz
- Bandwidth: 140 MHz
- Display Data Channel DDC: 1/2B

The data output of IBM compatible PCs can be connected directly to the projector using standard data cables. When connecting the projector to a Macintosh computer equipped with a 2 row, 15 pin connector a VGA/MAC adaptor (available at your PC store) is required. If your computer is equipped with a 3 row connector no adaptor is needed.

Universal Serial Bus (USB)

The Universal Serial Bus (USB) connector allows you to connect to computers equipped with a USB interface, resulting in real hot plug and play presentation.

Mouse control

By connecting USB, the mouse function on the Remote Control automatically gets installed. You can now manipulate the mouse cursor on the computer and on the screen, using Cursor Control on the remote control. The Mouse Left/Right buttons on the remote control function as Left and Right mouse keys of your pc.

Note

Based on the specific hardware and software configuration available, Apple Macintosh computer users could experience incomplete or erratic USB functionality. These problems are not related to the performance of your projector.


External monitor connection

A separate external monitor (or a second projector) can be connected to the projector. The image projected is simultaneously shown on the monitor, even when the projector is in Power/Standby or Off mode.

CAUTION

Always switch off projector and external equipment before making any connections.


General information <



Component/HD TV

Pr, Y, Pb/Cr, Y, Cb

- 1 Connect the Component in sockets of the projector to the appropriate output sockets of your Component- or HDTV-video equipment (Pr, Y, Pb / Cr, Y, Cb).
For this, use the audio/video connection cable supplied **(1)**.
- 2 If required you can connect the Audio out L/R sockets of the Component- or HDTV-video equipment to the Audio (in) L/R sockets of the projector.
For this, use an optional audio connection cable **(2)**.
 - Audio information from the Component- or HDTV-video equipment will be played via the projector speaker.




CVBS

- 1 Connect the Video (out) socket of a VCR, Laser Disc player, video camera or TV to the Video (in) socket of the projector.
For this, use the video/audio connection cable **(1a)** supplied.
- 2 Connect the Audio out L/R sockets of the VCR, Laser Disc player, video camera or TV to the Audio (in) L/R sockets of the projector.
For this, use the audio/video connection cable supplied **(1b)**.

S-VHS

- 1 Connect the S-Video (out) socket of a S-VHS video recorder, Laser Disc player, video camera or TV to the S-Video (in) socket of the projector.
For this use the S-Video connection cable supplied **(2)**.
- 2 Connect the Audio out L/R sockets of the S-VHS video recorder, Laser Disc player, video camera or TV to the Audio (in) L/R sockets of the projector.
For this, use audio/video connection cable supplied **(1b)**.

Scart connection




Scart adapter
(not for USA version)

CVBS


- 1 Connect the Scart/RCA Audio Video adapter supplied to the Scart connector of the VCR, Laser Disc player, video camera or TV.
- 2 Plug the video/audio connection cable supplied into both the adapter and the Video and Audio (in) L/R sockets of the projector.

S-VHS

- 3 Plug the S-Video connection cable supplied into the VCR and the S-Video socket of the projector.




Scart adapter
(not for USA version)




Scart connection

RGBS

- 1 Connect the Scart/RCA Component Video adapter supplied (1) to the Scart connector of your Component- or HDTV-video equipment.
- 2 Connect the Component in sockets of the projector to the R, G and B outputs of the adapter.
For this, use the audio/video connection cable supplied (2).
- 3 Connect the Video input of the projector to the Y output of the adapter.
For this, use an optional audio/video connection cable (3).
- 4 Select 'RGBS' input by pressing the Source button.



- 'RGBS' appears on the screen.
- 5 If required you can connect the Audio out L/R sockets of the Component- or HDTV-video equipment to the Audio (in) L/R sockets of the projector.
For this, use an optional audio connection cable (4).
 - Audio information from the Component- or HDTV-video equipment will be played via the projector speaker.





PC/Macintosh

- 1 Connect the Data (out) socket of the computer to the Computer (in) socket of the projector and secure the plugs by tightening the thumb screws.
For this, use the VGA cable supplied (1).
 - 2 Connect the USB (upstream) socket of the projector to the USB downstream port of the computer.
For this, use an optional USB cable (2).
- or:
- 2 Connect the PS/2 (out) socket of the projector to the PS/2 (in) socket of the computer.
For this, use an optional PS/2 cable (3).
- When switching on, first switch on the projector and then the PC.
 - You can now manipulate the mouse cursor on the computer and on the screen, using Cursor Control on the remote control. When using the USB connection, make sure Windows 98, Windows ME, Windows 2000 or Windows XP is installed on the computer.
 - The display settings of the computer will be changed to fit the capability of the projector.
- 3 If required you can connect the Audio out socket of the computer to the Audio in Computer socket of the projector.
For this, use an optional audio cable (4).
 - Audio information from the Computer will then be played via the projector speaker.

4. Installation

Connecting to a computer <



Connecting to an external monitor

- 1 Connect the VGA Y connector marked 'Projector' **(5a)** of an optional VGA Y cable, to the Computer (in) socket of your projector.
- 2 Connect the VGA cable supplied **(1)** between the computer and the VGA Y connector marked 'Computer' **(5b)**.
- 3 Connect the VGA Y connector marked 'Monitor' **(5c)** to the VGA cable **(6)** of the monitor.
- 4 Switch on your Computer.
- 5 Select 'Computer' input, using the Source button.
- 6 'Computer' appears on the screen.
- 7 Press Menu.
- 8 The menu bar appears on the screen.
Use Cursor Control to select 'Settings' in the menu bar.
- 9 Use Cursor Control to select 'Monitor out'.
- 10 Use Cursor Control to select 'On'.
The projector will indicate the necessity to connect the Y cable.
Switch on the external monitor.
- 11 The image projected is simultaneously shown on the monitor.

5. Operation

Preparation <

- 1 Press the Standby button to switch on the projector.
 - The Standby indicator lights up orange.
 - When the projection lamp is on, the Standby indicator lights up green and the start-up screen (when enabled) appears for several seconds.
- 2 Select the required source (Video, S-Video, Component, RGBS, Computer) by pressing the Source button.
 - When only one input source is connected, this source will automatically be selected (AutoSet). When more input sources are connected, the source with the highest priority will be selected (Video, S-Video, Component, RGBS, Computer). Source selection can be changed in the 'Settings' menu.
- 3 Switch on the computer or start video playback.
 - A feedback message appears on the screen, indicating the selected source.

General explanation

Messages are displayed in the centre of the screen. The problem is described in the header of the message display. Suggestion(s) to solve the problem are displayed in the gray part of the message display.

Feedback messages

Feedback messages are displayed in the top right corner of the screen. They are displayed when:


- a signal comes up or goes down;
- when an input source is changed;
- when Mute or AV Mute is activated;
- when the Auto Image function is set to On.

Some examples


These messages will only be displayed when the menu option 'Feedback' is set to 'On' in the Settings' menu. All messages will be removed automatically after 4 seconds.



Computer selected as source




Video selected as source,
no input signal


S-Video selected as source,
AW mutedComponent selected as source *A/V muted*

5. Operation



On Screen Display Menu >




Menu tree



VIDEO/S-VIDEO MODE




COMPUTER MODE







5. Operation

On Screen Display Menu >

COMPUTER MODE







GENERAL ADJUSTMENTS/SETTINGS



5. Operation

On Screen Display Menu >

General explanation



1 Press Menu.

- The menu bar appears on the screen.
- The first item is highlighted and its sub menu is shown.

Depending on the selected source (Video, S-Video, Component, RGBS, Ordenador) some options of the submenu may be greyed out. This indicates that these functions:

- are not available in a certain mode.
 - have no function for the selected source.
- For example:

- Horizontal size under menu 'Display' when Auto image is switched to ON.
- Hue under menu 'Picture' when signaltype is not NTSC.

- 2 Use Cursor Control left and/or right to move the cursor to any other item in the menu bar.
- 3 Select the sub menu item to be adjusted using Cursor Control up and/or down. When more items are available than can be shown in one screen, this will be indicated by 'more' at the bottom of the list. Move the cursor down to go to the next list of items. With 'previous' you can go back to the first list.

- 4 Adjust the selected item in the action window at the bottom of the screen, using Cursor Control left, and/or right.

- 5 Select the next item to be adjusted in the sub menu and adjust as described above.

- 6 Press Menu to close the On Screen Menu Display.

5. Operation

On Screen Display Menu >

For Video/S-Video signal input, the following 'Picture' and 'Display' adjustments can be made:

Picture adjustments

- Press Menu and select 'Picture' in the menu bar. The following 'Picture' adjustments can now be made according to the instructions under 'General explanation'.

For adjustment of 'Picture Format', see explanation under 'Computer adjustments'.

- **Picture Format**
selects one of six picture format options (wide screen, super zoom 4:3, 4:3, movie expand 14:9, movie expand 16:9, 16:9 subtitles);

- **Contrast**
adjusts the overall contrast intensity;

- **Colour tracking**
selects between 'Vivid' and 'Natural' representation of colours in the picture.

'Vivid' is automatically set when computer input is used;

'Natural' is automatically set when video input is used.

- **Saturation**
adjusts the colour saturation of the projected image;

- **Hue (only for NTSC)**
adjusts the tint of the projected image;

- **Sharpness**
controls the contour impression of the picture;

- **Colour temperature**
adjusts the overall colour impression from warm to cool.

The various colours (red, green and blue) can also be adjusted individually;

- **Brightness**
adjusts brightness of the displayed picture;

- **Mirror**
mirrors the picture for use of the projector in various positions with respect to the user(s) and the projection screen.

Display adjustments

- Press Menu and select 'Display' in the menu bar. The following 'Display' adjustments can now be made according to the instructions under 'General explanation'.

For adjustment of 'Digital Zoom/Magnification', see explanation under 'Computer

adjustments'.

- **Digital Freeze**
captures a moving picture (still picture);




- **Digital Zoom**
enlarges a part of the picture;

- **Magnification**
adjusts the zoom factor.

5. Operation

On Screen Display Menu >

Computer adjustments



Tip for Windows users

To adjust size and phase correctly

- 1 Select 'Start' and then 'Shut down' from the Windows taskbar.
- 2 Adjust the projector's size control, so that no vertical bars are visible.
- 3 Now adjust the projector's phase control for maximum brightness of the projected image.
- 4 Press 'No' in the Windows shutdown screen to cancel the shutdown action.

For computer signal input, the following 'Picture' and 'Display' adjustments can be made.

Picture adjustments

- Press Menu and select 'Picture' in the menu bar. The following 'Picture' adjustments can now be made according to the instructions under 'General explanation':
 - **Picture Format**
selects one of six picture format options (wide screen, super zoom 4:3, 4:3, movie expand 14:9, movie expand 16:9, 16:9 subtitles);
 - **Contrast**
adjusts the overall contrast intensity;
 - **Colour tracking**
selects between 'Vivid' and 'Natural' representation of colours in the picture. 'Vivid' is automatically set when computer input is used;
 - **Natural**
'Natural' is automatically set when video input is used;
 - **Colour temperature**
adjusts the overall colour impression from warm to cool. The various colours (red, green and blue) can also be adjusted individually.
 - **Brightness**
adjusts brightness of the displayed picture;
 - **Mirror**
mirrors the picture for use of the projector in various positions with respect to the user(s) and the projection screen.

Display adjustments

- Press Menu and select 'Display' in the menu bar. The following 'Display' adjustments can now be made according to the instructions under 'General explanation':
 - **Picture In Picture**
Projects a Video or S-Video picture in the currently projected computer picture;
 - **Digital Freeze**
captures a moving picture (still picture);
 - **Digital Zoom**
enlarges a part of the picture;
 - **Magnification**
adjusts the zoom factor;
 - **Auto Image**
automatically sizes and positions the image to fit optimally in the screen picture;
 - **Horizontal size**
adjusts the computer image in a horizontal direction to make the image completely fill the screen;
 - **Phase**
minimises picture imperfections. When connecting the projector to your PC for the first time, be sure to adjust the phase control for optimal readability of the projected text;
 - **Shift**
adjusts the computer image in horizontal and vertical direction to centre it on the screen.

5. Operation

On Screen Display Menu >

For computer signal input, the following 'Picture' and 'Display' adjustments can be made.

Picture adjustments

- Press Menu and select 'Picture' in the menu bar. The following 'Picture' adjustments can now be made according to the instructions under 'General explanation':
 - **Picture Format**
selects one of six picture format options (wide screen, super zoom 4:3, 4:3, movie expand 14:9, movie expand 16:9, 16:9 subtitles);
 - **Contrast**
adjusts the overall contrast intensity;
 - **Colour tracking**
selects between 'Vivid' and 'Natural' representation of colours in the picture. 'Vivid' is automatically set when computer input is used;
 - **Natural**
'Natural' is automatically set when video input is used;
 - **Colour temperature**
adjusts the overall colour impression from warm to cool. The various colours (red, green and blue) can also be adjusted individually.
 - **Brightness**
adjusts brightness of the displayed picture;
 - **Mirror**
mirrors the picture for use of the projector in various positions with respect to the user(s) and the projection screen.

Display adjustments

- Press Menu and select 'Display' in the menu bar. The following 'Display' adjustments can now be made according to the instructions under 'General explanation':
 - **Picture In Picture**
Projects a Video or S-Video picture in the currently projected computer picture;
 - **Digital Freeze**
captures a moving picture (still picture);
 - **Digital Zoom**
enlarges a part of the picture;
 - **Magnification**
adjusts the zoom factor;
 - **Auto Image**
automatically sizes and positions the image to fit optimally in the screen picture;
 - **Horizontal size**
adjusts the computer image in a horizontal direction to make the image completely fill the screen;
 - **Phase**
minimises picture imperfections. When connecting the projector to your PC for the first time, be sure to adjust the phase control for optimal readability of the projected text;
 - **Shift**
adjusts the computer image in horizontal and vertical direction to centre it on the screen.



Some examples

The following 'Display' adjustment procedures, follow a slightly different sequence of actions, or may need some further explanation.

Picture Format

'Picture Format' is used to select one of six picture format options (wide screen, super zoom 4:3, 4:3, movie expand 14:9, movie expand 16:9, 16:9 subtitles). Default mode for computer signal input at each start up of the projector is 4:3. For video signal input, the picture format will be selected that was selected the last time the projector was switched on.

- 1 Press Menu.
- The menu bar will appear.
- 'Picture' is highlighted and its sub menu is shown.
- 2 Use Cursor Control to move the cursor to 'Picture Format'.
- 3 Select the desired picture format.
 - Selected picture format is activated. See also 'Vertical shift'.
- 4 If required, select the next item to be adjusted or press Menu to exit.



Note


With the Picture Format (P) button on the remote control, you can toggle through the various picture formats. A feedback message on the screen indicates the selected picture format.

Vertical Shift

(after selecting picture format for video input signal)

Due to the scaling of the image when the picture format is changed, it might be possible that a part of the actual image is missing at the top or the bottom of the screen. When one of the picture formats 'super zoom 4:3', 'movie expand 14:9', 'movie expand 16:9', '16:9 subtitles' is selected and confirmed by pressing OK, the Vertical Shift function is activated. This allows you to correct the position of the projected image upwards or downwards.

- 1 Use Cursor Control to move the projected image upwards or downwards.
- 2 Press OK to confirm and store the adjustment.
- 3 If required, select the next item to be adjusted or press Menu to exit.




Note

When the 'Vertical shift' window has been removed you can also the Cursor Control Up/Down buttons on the projector or the remote control to move the image upwards/downwards.

Shift

The Shift function adjusts the computer image in horizontal and vertical direction to centre it on the screen. This function is only active when 'Auto Image' is set to 'Off'.

- 1 Press Menu.
- The menu bar will appear.
- 2 Use Cursor Control to move the cursor to 'Display'.
- 3 Use Cursor Control to move the cursor to 'Shift'.
- 4 Press OK to activate Shift.
- The menu bar will appear.
- 5 Use Cursor Control to position the computer image.
- 6 Press OK to confirm and store the adjustment.
- 7 If required, select the next item to be adjusted or press Menu to exit.



Auto Image

The Auto Image function automatically sizes and positions the image to fit optimally in the screen picture. In addition, it takes care of phase adjustment. It does not affect the selected picture format. When Auto Image is set to On, the Horizontal size, Shift and Phase options are greyed out.



Horizontal size

The Horizontal size function is used to size a computer image to make it fit the projected picture. When the OSD menu is active and the horizontal size option is selected, the level will be indicated graphically on a linear scale (slider).

Digital Zoom/Magnification

'Digital Zoom' is used to enlarge a part of the picture.

- 1 Press Menu.
- The menu bar will appear.
- 2 Use Cursor Control to move the cursor to 'Display'.
- 3 Use Cursor Control to move the cursor to 'Digital Zoom'.
- 4 Select 'On' to switch 'Digital Zoom' on.
 - Press OK to continue, or
 - Press Menu to exit and continue with the previous Zoom settings.
- 5 Use the zoom target to select centre of the screen area you wish to enlarge.
 - Press OK to confirm.
- 6 Use the Magnification slider to adjust the Zoom factor.
 - Press OK to confirm and exit the menu.
- 7 Use Cursor Control to select another section of the enlarged area ('Panning').





Picture in picture (PIP)

PIP enables the projection of a Video or S-Video picture in the currently projected computer picture.

- 1 Press Menu.
- The menu bar will appear.
- 2 Use Cursor Control to move the cursor to 'Display'.
- 3 Use Cursor Control to move the cursor to 'Picture in Picture'.
- 4 Select the required picture size ('Small', 'Medium' or 'Large') or select 'Off' to switch off PIP.
- 5 Use Cursor Control to move the cursor to 'Source'.
- 6 Select the source ('Video' or 'S-Video') from which you wish to project the picture in the currently projected computer picture.

If you select 'Auto' the system will check if there is a source available that can be displayed in the PIP window. If such a source is found then it will be displayed.
- 7 Use Cursor Control to move the cursor to 'Position'.
- 8 Press OK to confirm.
- The 'PIP Position' window will appear.
- 9 Use Cursor Control to position the 'PIP' window.
- 10 Press OK to confirm.




Note

Please note that only Video and S-Video sources can be displayed in the PIP window and only when the main window is displaying a computer source (or no source at all). Any invalid combination will result in a black PIP window for the main window has priority.

5. Operation

On Screen Display Menu <

General adjustments




Audio adjustments

- Press Menu and select Audio in the menu bar. The following Audio adjustments can now be made for both Computer, Component and Video/S-video input, according to the instructions under 'General explanation':
 - Volume adjusts the sound level;
 - Bass adjusts the bass tones;
 - Treble adjusts the high tones;
 - Mute mutes the sound of the projector.

The volume can also be adjusted with the - Volume + keys on the remote control and local keyboard.

General settings




- The projector is equipped with the following functions to optimize its use and handling. Press Menu and select Settings in the menu bar. The following settings/adjustments can now be made for both Computer, Component and Video/S-video input, according to the instructions under 'General explanation':
 - Language

- To select the required menu language;
 - Keystone correction
- To correct picture distortion of the vertical keystone type by internal scaling;
 - System information
- The System Information sub menu contains an overview of the most relevant projector settings, including information on the hardware and software configuration;
 - Factory reset
- To reset all user settings to the default factory settings;
 - Key lock
- To de-activate all remote and local controls. To disable the keylock function keep the OK button pressed for 10 seconds;
 - SmartSave
- To switch off SmartSave mode or to select the delay time after which the projector automatically switches to Standby;
 - Start-up screen
- To display or suppress the default Philips start-up screen upon the projector's start up;
 - SmartSet
- To switch automatic source selection on or off;
 - Feedback
- To suppress OSD messages. Warning or error messages however are never suppressed;
 - Lamp counter
- To show the operating time of the lamp, which can be reset after a new lamp has been installed;
 - Monitor out
- Enables image on second monitor connected.

6. Maintenance



Cleaning



Cleaning the cabinet

- When the cabinet is dusty, clean it by gently wiping with a soft cloth.
- A chamomile leather slightly moistened with water is sufficient for cleaning the housing.
- Do not use cleaning agents as they may harm the housing.

Cleaning the lens


- When the lens is dirty or dusty first blow the dust off and then gently wipe with a soft brush or lens cleaning paper. Never touch the lens with your fingers.
- The lens is likely to become mouldy if left dirty.

Cleaning the dust filter

Make sure to clean the dust filter regularly.

- Switch off the projector and wait until the cooling fan has stopped before disconnecting the projector.
- Turn the projector over. Never place the projector on the side where the connections are located!
- Press tab A and remove filter holder B from the projector.
- Press clamp C, open the holder and remove the filter.
- While firmly holding the filter, gently remove any accumulated dust from the dusty side, with a vacuum cleaner.
- Press clamp C, put the filter back in place and release clamp C. Firmly press the filter edges in place.
- Close the filter holder.
- Press tab A and insert the filter B into the projector.

Important



Notes

We advise you to clean the filter every 100 hours. Operating the projector without filter or with a torn or damaged filter may seriously damage the projector.





When the filter is damaged replace it with a filter of the same type (12 nc. 3122 434 0157 0).

The projector power cannot be switched on again unless the filter holder is installed correctly.



6. Maintenance

Lamp

When operation time reaches the last 100 hours of the average lamp life, the message 'Warning: lamp life has almost expired' will be displayed on the screen each time the projector is switched on. The lamp indicator lights up orange.






Lamp Replacement



6. Maintenance



Lamp replacement

- Unscrew screw B.
- Grasp the lamp holder handle and carefully pull the lamp holder out of the projector.
 - Do not tilt if the inner tube is broken glass particles may fall out.
 - Keep lamp holder opening to your right. Do not touch lamp or point lamp holder opening at anyone.
- Carefully remove the new lamp housing from its package.
 - Always use the same type of lamp: LCA3116/00 (132 W), 12inc-8670 931 16009.
 - Do not touch lamp or point lamp housing opening at anyone.
 - Do not drop as the impact may cause the lamp to break.
- Place the lamp holder in the guiding slots and insert into the lamp compartment.
- Tighten screw B again.



- Put the lamp door back in place and press tab A back in its original position.
 - The Mains inlet socket will open again.
- Insert the mains lead into both the projector Mains inlet socket and the wall socket.
- Press the Standby button to switch on the projector.
- Reset the lamp life time (see 'Resetting the lamp life time').
- Dispose of the old lamp in special chemical disposal bins.

Resetting the lamp life time



- Press Menu.
 - The menu bar appears on the screen.
- Use cursor control to select 'Settings' in the menu bar.
- Use cursor control to select 'Lamp counter' in the sub menu.

- Press OK for 3 seconds to reset the lamp counter.
- If required, select another item you wish to adjust or press Menu to exit.

7. Troubleshooting

If a fault occurs, first check the points listed below before taking the projector for repair. If you are unable to remedy a problem by following these hints, consult your dealer or service organisation.

Warning

Under no circumstances should you try to repair the projector yourself as this could invalidate the guarantee.

Read as follows

Problem

- Possible cause
- Solution

Image is not or incorrectly displayed

General

- Mains lead is not correctly connected.
- Correctly connect mains lead.
- The filter holder is not installed correctly or is damaged.
- Install the filter holder correctly (see 'Cleaning the dust filter' under 'Maintenance').
- Lamp holder cover is not closed correctly or the lamp holder is damaged.
- Close the cover correctly (see 'Lamp replacement' under 'Maintenance').
- Signal cable not correctly connected.
- Connect signal cable correctly.
- The projector is in Off position.
- Press Standby to switch on the projector.
- AVI Mute active.
- Cancel AVI Mute.
- 'Shift' and/or 'Horizontal size' are not adjusted correctly.
- Adjust 'Shift' or 'Horizontal size' (see 'Display adjustment' under 'Operation' - 'On Screen Display Menu').
- Activate the 'Auto-image' function via the On Screen Display menu.

In Component Video mode

- 'Auto Image' has not selected the correct settings for 'Shift' and/or 'Horizontal Size'.
- Adjust 'Shift' or 'Horizontal size' (see 'Display adjustment' under 'Operation' - 'On Screen Display Menu').
- Activate the 'Auto-image' function via the On Screen Display menu.
- Reset all settings to the default factory settings with the 'Factory reset' option in the 'Settings' menu.
- Keystoning is applied on a high resolution component signal.
- Decrease keystoning until the image is correctly displayed. For this use the ▽ Keystone buttons on the remote control or the 'Keystone correction' option in the 'Settings' menu.

7. Troubleshooting

In Data mode

- Input resolution is too high (and keystoning is applied).
- If you wish to keep the keystone correction, decrease the input resolution until the image is correctly displayed. For this, refer to the User Guide or support information of the computer.
- If you wish to keep the input resolution as it is, decrease keystoning until the image is correctly displayed. For this, use the ▽ Keystone Δ buttons on the remote control or the 'Keystone correction' option in the 'Settings' menu.
- Input resolution is too high (and no keystoning is applied).
- Decrease the input resolution until the image is correctly displayed. For this, refer to the User Guide or support information of the computer.

In case of RGBS (Scart) connection:

- RGBS is not selected or SmartSet is activated (does not recognize RGBS).
- Select RGBS as projection source with the Source button on the projector or the remote control.
- Adjust 'Brightness', 'Contrast', 'Saturation' or 'Hue' (see 'Picture adjustment' under 'Operation' - 'On Screen Display Menu').
- Reset all projector settings in the 'Settings' menu ('Factory reset').

Poor colour

Image is blurred

- Image is not focused.
- Adjust focus ring.
- Distance between projector and screen is not correct.
- Adjust the distance between the projector and the screen.

Picture rolls

- Signal cable is not correctly connected.
- Connect signal cable correctly.

No sound

- Audio cable is not correctly connected.
- Connect audio cable correctly.
- Volume is not adjusted properly.
- Adjust volume.
- (AVI)Mute active.
- Cancel (AVI)Mute.

7. Troubleshooting	The mouse cursor does not react when using the cursor control on the remote control	<div>7. Troubleshooting</div>	<div>The mouse cursor does not react when using the cursor control on the remote control</div>	<div>General:</div> <ul style="list-style-type: none">Check that the batteries are installed properly in the remote control and/or replace the batteries.Check that the projector receives the signals from the remote control.Check that the USB cable or PS/2 cable has been properly connected.Check that both projector and computer are switched on.Unplug the USB cable or PS/2 cable and then reconnect. <div>In case of PS/2 connection:</div> <ul style="list-style-type: none">The PS/2 mouse of the connected laptop has priority over the projector mouse loop through connection.Disable the PS/2 mouse of the laptop by selecting 'Disable in hardware profile' in the 'Windows Mouse Properties' of the laptop. Then restart 'Windows' on the laptop. The projector mouse loop through connection now has priority while the laptop mouse can still be used.Switch off all devices and then reconnect while you make sure that you:<ul style="list-style-type: none">connect the PS/2 cable to PC and projector before switching on the PC;switch on the projector before switching on the PC;do not connect the USB cable when making the PS/2 connection.Also refer to the User Guide or support information of your computer. <div>In case of USB connection:</div> <ul style="list-style-type: none">Connect another USB device (mouse, scanner, webcam, etc.) and see if it works. If it does not work there is a problem with the computer.Also refer to the User Guide or support information of the computer.'Windows' did not manage to install the driver correctly. In this case the 'Device manager' will contain a category 'Other devices'.<ul style="list-style-type: none">Disconnect the projector;Remove all items listed under 'Other devices' in the 'Device manager';Restart the computer;Reconnect the projector.In case the computer asks for monitor drivers, install the drivers on the CD-ROM supplied with the projector.In case the computer asks for a USB-device driver, install the required drivers on the CD-ROM supplied with the computer.
7. Troubleshooting	Picture too dark or bright with external monitor connected	<div>7. Troubleshooting</div>	<div>Picture too dark or bright with external monitor connected</div>	<div>Computer asks for drivers</div>
7. Troubleshooting	No reaction when pressing keys on local keyboard or remote control	<div>7. Troubleshooting</div>	<div>No reaction when pressing keys on local keyboard or remote control</div>	<div>Computer asks for drivers</div>
7. Troubleshooting	Indicators	<div>7. Troubleshooting</div>	<div>Indicators</div>	<div>Computer asks for drivers</div>
7. Troubleshooting	The projector does not react to commands from the remote control	<div>7. Troubleshooting</div>	<div>The projector does not react to commands from the remote control</div>	<div>Computer asks for drivers</div>
7. Troubleshooting	Note	<div>7. Troubleshooting</div>	<div>Note</div>	<div>Computer asks for drivers</div>
7. Troubleshooting	Garbo Matchline	<div>7. Troubleshooting</div>	<div>Garbo Matchline</div>	<div>Computer asks for drivers</div>

8. Optical alignments

8.1 Corner mirror Red

Put on a red picture. If dark bands are visible on the sides, loosen the two screws (A) fixing the mirror on top, and move the mirror till the dark bands are gone. Alternatively you can use a white picture (LCD panels not connected), and check for a red or yellow bar at the sides.

8.2 Corner mirror Green



Put on a green picture. If dark bands are visible on the sides, loosen the two screws (B) fixing the mirror on top, and move the mirror till the dark bands are gone. Alternatively you can use a white picture (LCD panels not connected), and check for a green or cyan bar at the sides.

8.3 Corner mirror Blue

Put on a blue picture. If dark bands are visible on the sides, loosen the two screws (C) fixing the mirror on top, and move the mirror till the dark bands are gone. Alternatively you can use a white picture (LCD panels not connected), and check for a blue or magenta bar at the sides.


8.4 Polarizer adjustment

Put on a black picture. Loosen the screw (D) on top. Move the slider bar (E) minimal light in the picture. The same adjustment is valid for all three polarizer's.



8.5 Convergence alignment

In the standard configuration the convergence cannot be adjusted. If convergence adjustment is necessary (e.g. after replacing an LCD), this can only be done after replacing the LCD fixation screws by special screws. The alignment is then done by moving the LCD panel itself around the screws.



CL 26645004_084.eps
050802

For the alignment you need:

- 3122 435 40500 Special screws (2 for each LCD panel to be aligned).
- 3122 435 40510 Key "I", with which you can loosen and fasten the special screws (H).
- 3122 435 40520 Manipulator "J", which can be clamped over the LCD panel and move it.


Changing the screws

Remove the reco-unit from the engine by removing the 4 screws (F) (page 8.1).


Now remove the 2 screws G from the LCD panel to be aligned.

Now fix the LCD panel with 2 special screws (H), which are both fixed in the top holes of the LCD panel.


Place the reco unit back into the engine.




CL 26645004_083.eps
050802



CL 26645004_085.eps
050802



CL 26645004_081.eps
050802



CL 26645004_082.eps
050802

Aligning the convergence

With a the key (I), the 2 screws (H) can be loosened from the top. This is a critical action: the crews have to be loosed so that the LCD can be moved with some friction.

Now clamp the manipulator over the LCD panel. With the manipulator the LCD can be moved into the correct position. If the movement is too light or too difficult, readjust the tightness of screws (H).

Adjustment can best be done in the following order.

Lift the LCD up, so that the picture is below the original picture.

Now rotate the LCD, so that the vertical lines are parallel to the vertical lines of the original.

Now adjust the picture left/right, so that the sides match the sides of the original.


Now carefully push the LCD panel down, keeping the sides parallel, until the picture is correct.

If you do not get the required result, sometimes a small correction can be done, but otherwise it is better to start over again.

If the convergence is within specification (< 1 pixel), carefully fix the screws (H), to fix the LCD. If necessary fix the LCD with some glue or lacquer, before fixing the screws.



CL 26645004_086.eps
050802




CL 26645004_087.eps
050802

9. Parts list


Mechanical parts

2	TOP ASSY	3103 437 50600
2	TOP ASSY ML	3103 437 50920
2-3	IR LENS	3122 434 01750
2-4	IR GLASS	3122 434 21400
2-5	CONTROL KNOBS	3122 434 21390
3 \$	FRONT COVER LACQUERED	3122 438 11850
4	Side Assy Garbo	3103 437 50610
4	Side Assy ML	3103 437 50930
5	IO Side Assy Garbo	3103 437 50620
5	IO Side Assy ML	3103 437 50940
11	ZOOM RING LACQUERED	3122 438 11910
12	FOCUS RING ASSY	3103 437 50630
1001	Keyboard board	3122 438 51170
1002	IR-receiver board	3122 438 51180


CL 26645004_075.eps
120802

25	AIR GUIDE ASSY	3122 437 16420
26 \$	BRACKET PS	3122 434 01770
35-1 \$	HOUSING DUST FILTER	3122 434 01590
35-2 \$	frame dust filter	3103 437 50760
35-2 \$	frame dust filter ML	3103 437 50890
35-3 \$	Dust filter (foam)	3122 434 01570
35-4	FILTER RETAINER	3122 433 70600
36	Safety bracket	3122 434 02030
1001 \$	POWER SUPPLY MODULE	3122 438 00060
1006 \$	Lamp supply 132W SV1	9137 001 48403

15 \$	LIGHT SHIELD	3122 434 21600
19 \$	BRACKET FAN PCS	3122 434 01560
20 \$	LCD FAN BRACKET	3122 434 01740
33	CABLE RETAINER	3122 433 70620
1002	PCA DRB SVGA ED2 STER	3122 438 51420
1004	PCA SSB LC6231	3122 438 51150
1004	PCA SSB LC7181	3122 438 50910
1008 \$	FAN ASSY S10-MAIN FAN	3122 437 51250
1009 \$	FAN ASSY S12-PCS FAN	3122 437 51260
1010 \$	FAN ASSY S13-LCD FAN	3122 437 51270
8001 \$	Dust filter switch	3122 431 01820
8007 \$	Temperature switch + cable	3122 431 01680

CL 26645004_070.eps
120802

1	BOTTOM ASSY	3103 437 50590
1	BOTTOM ASSY ML	3103 437 50910
3 \$	LAMPDOOR	3103 437 50660
3 \$	LAMPDOOR ML	3103 437 50830
13 \$	FOOT LEG	3103 437 50680
13 \$	FOOT LEG ML	3103 437 50850
14 \$	FRONT FOOT	3103 434 20010



Cables

8001 \$	WIRE ASSY #3 MAINS-K3	3122 431 01730
8003 \$	Cable SSB/keyboard	3122 431 01840
8004 \$	WIRE ASSY #4 K04-S04	3122 431 01740
8001 \$	Cable keyboard/IR-board	3122 431 01780


Packaging

451	Carton box	3103 436 70080
451	Carton box ML	3103 436 70090
452	front-rear cushion	3122 126 40760
464	Outer box	3122 126 40370


Accessories

1-1 \$	Mains cord Euro	4822 321 11399
1-1 \$	Mains cord USA	4822 321 11294
1-1 \$	Mains cord UK	4822 321 11431
1-2	VGA Cable	3122 438 75110
1-3	AV cable	3122 438 71090
1-4	RCA JACK converter	3122 438 75130
1-6	RCA/SCART connector	2422 033 00345
1-7	S-video (Y/C) cable	3122 438 75140
2	DFU CD-ROM	3103 438 70060
3	QUICK SETUP CARD	3103 435 90020
3	QUICK SETUP CARD ML	3103 435 90060
4	DFU paper	3103 435 90030
4	DFU paper ML	3103 435 90070
5	CD-ROM wall paper	3103 435 90040
466	LENS CAP	3122 434 21540
1002	Remote control	3139 228 60500
1002	Remote control PRONTO NEO	3104 207 13810

Optical Parts



CL 26645004_078.eps
190602



CL 26645004_077.eps
190602

1	Lamp LCA3116/00 SV1	8670 931 16009
2	Integrator	3122 434 96230
3	Lens 2	3122 434 90920
4	Lens 3	3122 434 96150
5	Lens 4 Red	3122 434 96160
6	Lens 5	3103 434 90290
7	Lens 6	3103 434 90320
8	Compensation Plate	3103 434 90300

9	Mirror A	3122 434 92690
10	Mirror B	3122 434 92700
11	Mirror C	3122 434 92710
12	Mirror D1	3122 434 92720
13	Mirror D2	3122 434 92730
14-1	Flange	3122 434 01660
14-4	Adjust Plate Bottom	3122 431 35390
14-5	Projection Lens F1,8	3122 434 90810
14-6	Analyser Red Assy	3122 438 11710
14-7	Analyser Green Assy	3122 438 11580
14-8	Analyser Blue Assy	3122 438 11590
14-9	Dichroic X-Prism	3122 434 91560
15	M-Adjuster Bottom	3122 434 01470
16	Mirror-Adjuster	3122 434 10370
17	M-Stopper 1	3122 431 30930
18	M-Stopper 2	3122 431 30690
19	Polariser Red Assy	3122 438 11740
20	Polariser Green Assy	3122 438 11610
21	Polariser Blue Assy	3122 438 11620
22	UV-IR Filter	3122 434 94410
23	UV-Dichroic Filter	3122 434 94510
24	Integrator-PBS Assy	3103 437 50570
26	Lamp Cage	3122 434 01690
30	U-Base	3122 434 01700
31	U-Base Cover	3122 434 01710
33	Polaroid Holder	3122 434 01730

LCD Panels

1001	LCD L3d07s-21g01g	3122 430 02950
1002	LCD L3d07s-21g01r	3122 430 02960
1003	LCD L3d07s-21g01b	3122 430 02970

Small Signal Board**Connectors**

1210	VGA input	4822 267 51477
1300	6 * cinch video in	2422 026 05289
1320	Y/C - SVHS	4822 267 10994
1410	Driveboard BTB	2422 025 17279
1600	Power supply	2422 025 16545
1620	Temp switch	2422 025 15369
1710	keyboard	2422 025 17501
1720	PS2	2422 026 05257
1730	USB	2422 025 16606
1840	Phono 3.5 mm	4822 267 10985

1860	Temp switch	2422 025 15369
1902	Lamp driver	2422 025 16493
1910	Lamp driver	2422 025 16493
1911	Temp switch	2422 025 15369
1913	Lamp driver	2422 025 16493
1914	Temp switch	2422 025 15369

X-tals

1921	RES XTL 24M576	2422 543 89017
------	----------------	----------------

Capacitors

2000	0603 50V 100NP80M	2238 586 59812
2002	10UF 16V	4822 124 23002
2004	0603 50V 100NP80M	2238 586 59812
2006	0603 50V 100NP80M	2238 586 59812
2008	0603 50V 100NP80M	2238 586 59812
2010	0603 50V 100NP80M	2238 586 59812
2012	10UF 16V	4822 124 23002
2016	0603 50V 100NP80M	2238 586 59812
2018	10UF 16V	4822 124 23002
2020	0603 50V 100NP80M	2238 586 59812

2024	0603 50V 100NP80M	2238 586 59812
2026	0603 50V 100NP80M	2238 586 59812
2028	0603 NP0 50V 100P	2020 552 94427
2030	0603 NP0 50V 100P	2020 552 94427
2032	1UF +80-20% 16V 0805	4822 126 14043
2034	22UF 6.3V	4822 124 23237
2036	22UF 6.3V	4822 124 23237
2116	0603 50V 100NP80M	2238 586 59812
2118	33UF 20% 10V	4822 124 12077
2120	0603 50V 100NP80M	2238 586 59812

2122	0603 50V 100NP80M	2238 586 59812
2134	0603 50V 100NP80M	2238 586 59812
2136	10UF 16V	4822 124 23002
2138	10UF 16V	4822 124 23002
2140	0603 50V 100NP80M	2238 586 59812
2200	0603 50V 100NP80M	2238 586 59812
2201	0603 50V 100NP80M	2238 586 59812
2202	0603 50V 100NP80M	2238 586 59812
2203	0603 50V 100NP80M	2238 586 59812
2204	0603 50V 100NP80M	2238 586 59812

2205	0603 50V 100NP80M	2238 586 59812
2206	0603 50V 100NP80M	2238 586 59812
2207	0603 50V 100NP80M	2238 586 59812
2209	0603 50V 100NP80M	2238 586 59812
2210	0603 50V 100NP80M	2238 586 59812
2211	0603 50V 100NP80M	2238 586 59812
2212	0603 50V 100NP80M	2238 586 59812
2213	0603 50V 100NP80M	2238 586 59812
2214	0603 50V 100NP80M	2238 586 59812
2215	0603 50V 100NP80M	2238 586 59812

2216	0603 50V 100NP80M	2238 586 59812
2217	0603 50V 100NP80M	2238 586 59812
2218	10UF 16V	4822 124 23002
2219	0603 50V 100NP80M	2238 586 59812
2220	10UF 16V	4822 124 23002
2221	0603 50V 100NP80M	2238 586 59812
2223	10UF 16V	4822 124 23002
2224	0603 50V 100NP80M	2238 586 59812
2225	10UF 16V	4822 124 23002
2226	0603 16V 47N COL	3198 017 34730

2227	0603 50V 100NP80M	2238 586 59812
2228	0603 16V 47N COL	3198 017 34730
2229	0603 50V 100NP80M	2238 586 59812
2230	0603 16V 47N COL	3198 017 34730
2231	0603 50V 100NP80M	2238 586 59812
2233	1NF 10% 50V 0603	5322 126 11578
2235	6,8NF10%X7R 63V	5322 126 11582
2236	33N 16V O6O3	4822 126 14549
2237	3,3NF10%X7R 63V	5322 126 11579
2238	0603 NP0 25V 680P	3198 016 36810

2239	0603 50V 100NP80M	2238 586 59812
2300	0603 50V 100NP80M	2238 586 59812
2302	10UF 16V	4822 124 23002
2304	47UF 16V	4822 124 80151
2305	47UF 16V	4822 124 80151
2306	0603 50V 100NP80M	2238 586 59812
2308	0603 50V 100NP80M	2238 586 59812
2310	47UF20% 4V	4822 124 81058
2312	0603 50V 100NP80M	2238 586 59812
2314	0603 50V 100NP80M	2238 586 59812

2316	0603 50V 100NP80M	2238 586 59812
2318	0603 50V 100NP80M	2238 586 59812
2328	0603 16V 47N COL	3198 017 34730
2330	0603 16V 47N COL	3198 017 34730
2332	0603 16V 47N COL	3198 017 34730
2334	0603 16V 47N COL	3198 017 34730
2336	0603 16V 47N COL	3198 017 34730
2338	0603 16V 47N COL	3198 017 34730
2340	0603 16V 47N COL	3198 017 34730
2342	0603 16V 47N COL	3198 017 34730

2344	0603 16V 47N COL	3198 017 34730
2346	0603 16V 47N COL	3198 017 34730
2348	0603 16V 47N COL	3198 017 34730
2350	0603 16V 47N COL	3198 017 34730
2352	0603 16V 47N COL	3198 017 34730
2354	0603 16V 47N COL	3198 017 34730
2356	0603 16V 47N COL	3198 017 34730
2358	0603 16V 47N COL	3198 017 34730
2364	0603 NP0 50V 33P	2222 867 15339
2366	0603 NP0 50V 33P	2222 867 15339

2368	0603 NP0 25V 1N	3198 016 31020
2400	0603 50V 100NP80M	2238 586 59812
2401	0603 50V 100NP80M	2238 586 59812
2402	0603 50V 100NP80M	2238 586 59812
2403	0603 50V 100NP80M	2238 586 59812
2404	22UF 6.3V	4822 124 23237
2405	0603 50V 100NP80M	2238 586 59812
2406	0603 50V 100NP80M	2238 586 59812
2407	0603 50V 100NP80M	2238 586 59812
2408	0603 50V 100NP80M	2238 586 59812

2409	22UF 6.3V	4822 124 23237
2411	0603 50V 100NP80M	2238 586 59812
2412	0603 50V 100NP80M	2238 586 59812
2413	0603 50V 100NP80M	2238 586 59812
2414	0603 50V 100NP80M	2238 586 59812

2415	0603 50V 100NP80M	2238 586 59812
2416	0603 50V 100NP80M	2238 586 59812
2417	0603 50V 100NP80M	2238 586 59812
2418	0603 50V 100NP80M	2238 586 59812
2419	0603 50V 100NP80M	2238 586 59812
2420	0603 50V 100NP80M	2238 586 59812
2421	0603 50V 100NP80M	2238 586 59812
2500	0603 50V 100NP80M	2238 586 59812
2504	0603 50V 100NP80M	2238 586 59812
2510	0603 50V 100NP80M	2238 586 59812

2514	0603 50V 100NP80M	2238 586 59812
2516	10UF 16V	4822 124 23002
2600	10UF 16V	4822 124 23002
2602	10NF 10% 50V 0603	5322 126 11583
2604	0603 50V 100NP80M	2238 586 59812
2606	10UF 16V	4822 124 23002
2608	0603 50V 100NP80M	2238 586 59812
2610	10UF 16V	4822 124 23002
2612	10NF 10% 50V 0603	5322 126 11583
2614	0603 50V 100NP80M	2238 586 59812

2616	10NF 10% 50V 0603	5322 126 11583
2620	3,3NF10%X7R 63V	5322 126 11579
2622	10NF 10% 50V 0603	5322 126 11583
2624	0603 50V 100NP80M	2238 586 59812
2626	100UF 10V 20%	4822 124 12318
2628	100UF 10V 20%	4822 124 12318
2630	47UF 16V	4822 124 80151
2632	47UF 16V	4822 124 80151
2634	10UF 16V	4822 124 23002
2636	0603 50V 100NP80M	2238 586 59812

2638	10UF 16V	4822 124 23002
2640	0603 50V 100NP80M	2238 586 59812
2642	47UF 16V	4822 124 80151
2644	47UF 16V	4822 124 80151
2646	10UF 16V	4822 124 23002
2648	0603 50V 100NP80M	2238 586 59812
2650	47UF20% 4V	4822 124 81058
2652	0603 50V 100NP80M	2238 586 59812
2654	47UF 16V	4822 124 80151
2656	47UF 16V	4822 124 80151

2658	47UF 16V	4822 124 80151
2660	47UF 16V	4822 124 80151
2662	0603 50V 100NP80M	2238 586 59812
2716	0603 NP0 50V 100P	2020 552 94427
2725	0603 NP0 50V 100P	2020 552 94427
2726	0603 NP0 50V 100P	2020 552 94427
2727	0603 50V 100NP80M	2238 586 59812
2729	0603 50V 100NP80M	2238 586 59812
2731	10UF 16V	4822 124 23002
2733	0603 50V 100NP80M	2238 586 59812

2735	0603 50V 100NP80M	2238 586 59812
2737	470PF 5% 50V	4822 126 13881
2741	0603 NP0 50V 100P	2020 552 94427
2743	10UF 16V	4822 124 23002
2747	0603 50V 100NP80M	2238 586 59812
2749	0603 50V 100NP80M	2238 586 59812
2800	0603 50V 100NP80M	2238 586 59812
2802	0603 50V 100NP80M	2238 586 59812
2804	33UF 20V 20%	4822 124 12316
2806	0603 50V 2N2 COL R	4822 126 14238

2808	100UF 20% 16V	4822 124 12095
2810	100UF 20% 16V	4822 124 12095
2818	0603 50V 100NP80M	2238 586 59812
2820	0603 50V 100NP80M	2238 586 59812
2848	33UF 20V 20%	4822 124 12316

2852 220NF +80-20% 16V 4822 126 13879
 2854 0603 50V 100NP80M 2238 586 59812
 2856 0603 50V 100NP80M 2238 586 59812
 2858 0603 16V 47N COL 3198 017 34730
 2860 0603 50V 100NP80M 2238 586 59812
 2862 0603 50V 100NP80M 2238 586 59812
 2864 0603 50V 100NP80M 2238 586 59812
 2866 0603 50V 100NP80M 2238 586 59812
 2868 0603 50V 100NP80M 2238 586 59812
 2870 0603 50V 2N2 COL R 4822 126 14238

2872 0603 NPO 50V 330P 4822 126 14241
 2874 0603 NPO 50V 330P 4822 126 14241
 2876 0603 NPO 50V 330P 4822 126 14241
 2878 0603 NPO 50V 330P 4822 126 14241
 2880 1NF 10% 50V 0603 5322 126 11578
 2881 1NF 10% 50V 0603 5322 126 11578
 2882 1NF 10% 50V 0603 5322 126 11578
 2883 1NF 10% 50V 0603 5322 126 11578
 2900 0603 50V 100NP80M 2238 586 59812
 2902 10UF 16V 4822 124 23002

2904 0603 50V 100NP80M 2238 586 59812
 2906 47UF 16V 4822 124 80151
 2910 10NF 10% 50V 0603 5322 126 11583
 2912 0603 50V 100NP80M 2238 586 59812
 2914 10UF 16V 4822 124 23002
 2916 33UF 20V 20% 4822 124 12316
 2918 10NF 10% 50V 0603 5322 126 11583
 2920 0603 50V 100NP80M 2238 586 59812
 2922 10UF 16V 4822 124 23002
 2924 10UF 16V 4822 124 23002

2926 47UF 16V 4822 124 80151
 2928 10NF 10% 50V 0603 5322 126 11583
 2930 0603 NPO 50V 100P 2020 552 94427
 2932 0603 50V 100NP80M 2238 586 59812
 2936 0603 50V 100NP80M 2238 586 59812
 2937 0603 50V 100NP80M 2238 586 59812
 2946 0603 50V 100NP80M 2238 586 59812

Resistors

3000 10K00 5% 0,062W 4822 051 30103
 3002 100R00 5% 0,062W 4822 051 30101
 3004 10K00 5% 0,062W 4822 051 30103
 3006 75R 1% 0,1W 4822 117 11927
 3007 100R00 5% 0,062W 4822 051 30101
 3008 100R00 5% 0,062W 4822 051 30101
 3009 100R00 5% 0,062W 4822 051 30101
 3012 100R00 5% 0,062W 4822 051 30101
 3014 330R00 5% 0,062W 4822 051 30331
 3016 100R00 5% 0,062W 4822 051 30101

3018 100R00 5% 0,062W 4822 051 30101
 3020 10K00 5% 0,062W 4822 051 30103
 3028 10K00 5% 0,062W 4822 051 30103
 3030 75R 1% 0,1W 4822 117 11927
 3032 1K00 5% 0,062W 4822 051 30102
 3034 1R 5% 0,062W 0603 4822 117 12917
 3036 4K70 5% 0,062W 4822 051 30472
 3038 33K00 5% 0,062W 4822 051 30333
 3040 330R00 5% 0,062W 4822 051 30331
 3042 2K20 5% 0,062W 4822 051 30222

3044 2K20 5% 0,062W 4822 051 30222
 3046 100R00 5% 0,062W 4822 051 30101
 3048 100R00 5% 0,062W 4822 051 30101
 3054 75R 1% 0,1W 4822 117 11927
 3056 2K20 5% 0,062W 4822 051 30222

3058 330R00 5% 0,062W 4822 051 30331
 3060 100R00 5% 0,062W 4822 051 30101
 3062 10K00 5% 0,062W 4822 051 30103
 3064 47K 1% 0,063W 0603 4822 117 12925
 3066 10K00 5% 0,062W 4822 051 30103
 3068 10K00 5% 0,062W 4822 051 30103
 3070 22K00 5% 0,062W 4822 051 30223
 3072 4K70 5% 0,062W 4822 051 30472
 3074 2K20 5% 0,062W 4822 051 30222
 3076 47K 1% 0,063W 0603 4822 117 12925

3078 100R00 5% 0,062W 4822 051 30101
 3080 100R00 5% 0,062W 4822 051 30101
 3086 15K 1% 0,063W 0603 5322 117 13033
 3088 15K 1% 0,063W 0603 5322 117 13033
 3090 10K 1% 0,063W 0603 4822 117 12706
 3092 1K00 5% 0,062W 4822 051 30102
 3094 1K00 5% 0,062W 4822 051 30102
 3110 1K50 5% 0,062W 4822 051 30152
 3112 RST NETW 4X22R 2350 035 10229
 3124 33R00 5% 0,062W 4822 051 30339

3130 470R00 5% 0,062W 4822 051 30471
 3138 RST NETW 4X15K 2350 035 10153
 3144 RST NETW 4X15K 2350 035 10153
 3200 NETW 4 X 33R 5% 1206 4822 117 13576
 3205 NETW 4 X 33R 5% 1206 4822 117 13576
 3210 NETW 4 X 33R 5% 1206 4822 117 13576
 3214 NETW 4 X 33R 5% 1206 4822 117 13576
 3218 NETW 4 X 33R 5% 1206 4822 117 13576
 3221 68R 5% 0,063W 0603 4822 051 30689
 3223 NETW 4 X 33R 5% 1206 4822 117 13576

3226 68R 5% 0,063W 0603 4822 051 30689
 3229 68R 5% 0,063W 0603 4822 051 30689
 3230 NETW 4 X 33R 5% 1206 4822 117 13576
 3231 NETW 4 X 33R 5% 1206 4822 117 13576
 3235 100R00 5% 0,062W 4822 051 30101
 3236 NETW 4 X 33R 5% 1206 4822 117 13576
 3237 100R00 5% 0,062W 4822 051 30101
 3239 100R00 5% 0,062W 4822 051 30101
 3242 NETW 4 X 33R 5% 1206 4822 117 13576
 3243 10K00 5% 0,062W 4822 051 30103

3245 10K00 5% 0,062W 4822 051 30103
 3247 3K30 5% 0,062W 4822 051 30332
 3249 NETW 4 X 33R 5% 1206 4822 117 13576
 3250 100R00 5% 0,062W 4822 051 30101
 3252 100R00 5% 0,062W 4822 051 30101
 3255 NETW 4 X 33R 5% 1206 4822 117 13576
 3259 NETW 4 X 33R 5% 1206 4822 117 13576
 3300 4K70 5% 0,062W 4822 051 30472
 3301 18R00 2% 0,25W 4822 051 10189
 3302 18R00 2% 0,25W 4822 051 10189

3303 18R00 2% 0,25W 4822 051 10189
 3304 18R00 2% 0,25W 4822 051 10189
 3305 18R00 2% 0,25W 4822 051 10189
 3307 18R00 2% 0,25W 4822 051 10189
 3309 56R00 2% 0,25W 4822 051 10569
 3311 56R00 2% 0,25W 4822 051 10569
 3312 RST NETW 4X47R 2350 035 10479
 3313 56R00 2% 0,25W 4822 051 10569
 3314 RST NETW 4X47R 2350 035 10479
 3315 56R00 2% 0,25W 4822 051 10569

3316 RST NETW 4X47R 2350 035 10479
 3317 56R00 2% 0,25W 4822 051 10569
 3319 56R00 2% 0,25W 4822 051 10569
 3321 470R00 5% 0,062W 4822 051 30471
 3323 3K30 5% 0,062W 4822 051 30332

3325 RST NETW 4X47R 2350 035 10479
 3327 RST NETW 4X47R 2350 035 10479
 3341 100R00 5% 0,062W 4822 051 30101
 3342 100R00 5% 0,062W 4822 051 30101
 3401 470R00 5% 0,062W 4822 051 30471
 3403 470R00 5% 0,062W 4822 051 30471
 3404 1K00 5% 0,062W 4822 051 30102
 3410 NETW 4 X 33R 5% 1206 4822 117 13576
 3414 NETW 4 X 33R 5% 1206 4822 117 13576
 3416 NETW 4 X 33R 5% 1206 4822 117 13576

3420 NETW 4 X 33R 5% 1206 4822 117 13576
 3424 NETW 4 X 33R 5% 1206 4822 117 13576
 3428 NETW 4 X 33R 5% 1206 4822 117 13576
 3438 NETW 4 X 33R 5% 1206 4822 117 13576
 3447 0R00 JUMPER 4822 051 30008
 3449 0R00 JUMPER 4822 051 30008
 3450 4K70 5% 0,062W 4822 051 30472
 3454 RST NETW 4X47R 2350 035 10479
 3455 RST NETW 4X47R 2350 035 10479
 3457 4K70 5% 0,062W 4822 051 30472

3458 4K70 5% 0,062W 4822 051 30472
 3500 3K30 5% 0,062W 4822 051 30332
 3502 22K00 5% 0,062W 4822 051 30223
 3508 100R00 5% 0,062W 4822 051 30101
 3510 100R00 5% 0,062W 4822 051 30101
 3516 3K30 5% 0,062W 4822 051 30332
 3526 3K30 5% 0,062W 4822 051 30332
 3531 100R00 5% 0,062W 4822 051 30101
 3602 47R00 5% 0,062W 4822 051 30479
 3604 100R00 5% 0,062W 4822 051 30101

3606 100R00 5% 0,062W 4822 051 30101
 3608 100R00 5% 0,062W 4822 051 30101
 3610 1R 5% 0,062W 0603 4822 117 12917
 3612 100R00 5% 0,062W 4822 051 30101
 3614 4K70 5% 0,062W 4822 051 30472
 3616 3K30 5% 0,062W 4822 051 30332
 3618 4K70 5% 0,062W 4822 051 30472
 3620 4K70 5% 0,062W 4822 051 30472
 3622 3K30 5% 0,062W 4822 051 30332
 3624 100R00 5% 0,062W 4822 051 30101

3626 4K70 5% 0,062W 4822 051 30472
 3628 100R00 5% 0,062W 4822 051 30101
 3630 3K30 5% 0,062W 4822 051 30332
 3636 100R00 5% 0,062W 4822 051 30101
 3640 4K70 5% 0,062W 4822 051 30472
 3664 1R 5% 0,062W 0603 4822 117 12917
 3666 390R00 5% 0,062W 4822 051 30391
 3668 12K00 5% 0,062W 4822 051 30123
 3670 47R00 5% 0,062W 4822 051 30479
 3672 47R00 5% 0,062W 4822 051 30479

3674 3K30 5% 0,062W 4822 051 30332
 3682 3K30 5% 0,062W 4822 051 30332
 3686 3K30 5% 0,062W 4822 051 30332
 3690 100R00 5% 0,062W 4822 051 30101
 3691 33R00 5% 0,062W 4822 051 30339
 3701 4K70 5% 0,062W 4822 051 30472
 3702 4K70 5% 0,062W 4822 051 30472
 3703 100K 1% 0603 0.62W 4822 117 13632
 3704 100K 1% 0603 0.62W 4822 117 13632
 3705 47K 1% 0.063W 0603 4822 117 12925

3706 47K 1% 0.063W 0603 4822 117 12925
 3707 4K70 5% 0,062W 4822 051 30472
 3709 4K70 5% 0,062W 4822 051 30472
 3711 4K70 5% 0,062W 4822 051 30472
 3719 4K70 5% 0,062W 4822 051 30472

3721	RST NETW 4X4K7	2350 035 10472	3910	22K 1% 0.063W 0603	5322 117 13022	5300	4,7UH/20%)	4822 157 10333
3727	1K50 5% 0,062W	4822 051 30152	3912	1K2 1% 1/16W	4822 117 11817	5302	BLM21A601SPT	4822 157 71206
3728	RST NETW 4X470R	2350 035 10471	3916	1K2 1% 1/16W	4822 117 11817	5306	BLM21A601SPT	4822 157 71206
3729	470R00 5% 0,062W	4822 051 30471	3920	10R00 5% 0,062W	4822 051 30109	5308	10UH 10%	4822 157 71593
3730	4K70 5% 0,062W	4822 051 30472	3922	10K00 5% 0,062W	4822 051 30103	5310	BLM21A121SPT	4822 157 11506
3731	4K70 5% 0,062W	4822 051 30472	3924	10K00 5% 0,062W	4822 051 30103	5312	BLM21A121SPT	4822 157 11506
3732	100R00 5% 0,062W	4822 051 30101	3926	100R00 5% 0,062W	4822 051 30101	5314	BLM21A121SPT	4822 157 11506
3733	1K50 5% 0,062W	4822 051 30152	3928	1K0 1% 0.063W 0603	5322 117 13018	5316	BLM21A121SPT	4822 157 11506
3734	10K00 5% 0,062W	4822 051 30103	3930	3K3 1% 0.063W 0603	5322 117 13048	5318	BLM21A121SPT	4822 157 11506
3735	100R00 5% 0,062W	4822 051 30101	3932	15K 1% 0.063W 0603	5322 117 13033	5320	BLM21A121SPT	4822 157 11506
3736	1R 5% 0,062W 0603	4822 117 12917	3938	1R 5% 0,062W 0603	4822 117 12917	5510	BLM21A601SPT	4822 157 71206
3737	220R00 5% 0,062W	4822 051 30221	3940	1R 5% 0,062W 0603	4822 117 12917	5511	BLM21A601SPT	4822 157 71206
3738	4K70 5% 0,062W	4822 051 30472	3942	1K0 1% 0.063W 0603	5322 117 13018	5600	BLM21A601SPT	4822 157 71206
3739	5K6 5% 0,063W 0603	4822 051 30562	3944	47K 1% 0.063W 0603	4822 117 12925	5602	BLM21A601SPT	4822 157 71206
3740	10K00 5% 0,062W	4822 051 30103	3946	10K00 5% 0,062W	4822 051 30103	5604	BLM21A601SPT	4822 157 71206
3741	56K00 5% 0,062W	4822 051 30563	3954	3K3 1% 0.063W 0603	5322 117 13048	5608	BLM21A601SPT	4822 157 71206
3742	22K00 5% 0,062W	4822 051 30223	3956	100R00 5% 0,062W	4822 051 30101	5610	BLM21A601SPT	4822 157 71206
3745	4K70 5% 0,062W	4822 051 30472	3958	15K 1% 0.063W 0603	5322 117 13033	5612	BLM21A601SPT	4822 157 71206
3747	100R00 5% 0,062W	4822 051 30101	3960	100R00 5% 0,062W	4822 051 30101	5614	BLM21A601SPT	4822 157 71206
3749	100R00 5% 0,062W	4822 051 30101	3962	100R00 5% 0,062W	4822 051 30101	5616	BLM21A601SPT	4822 157 71206
3750	0R00 JUMPER	4822 051 30008	3964	560R00 5% 0,062W	4822 051 30561	5618	1UH/20%)	4822 157 11258
3800	4,7R 5% 0603 0,0016W	4822 117 13608	3972	4K70 5% 0,062W	4822 051 30472	5620	6,8UH 20% 7X7X3,2	4822 157 11789
3802	4,7R 5% 0603 0,0016W	4822 117 13608	3974	4K70 5% 0,062W	4822 051 30472	5622	1UH/20%)	4822 157 11258
3804	4,7R 5% 0603 0,0016W	4822 117 13608	3976	100R00 5% 0,062W	4822 051 30101	5624	BLM21A601SPT	4822 157 71206
3806	4,7R 5% 0603 0,0016W	4822 117 13608	3978	100R00 5% 0,062W	4822 051 30101	5626	BLM21A601SPT	4822 157 71206
3808	3K9 5% 0.063W 0603	4822 051 30392	3980	10K00 5% 0,062W	4822 051 30103	5628	BLM21A601SPT	4822 157 71206
3810	4,7R 5% 0603 0,0016W	4822 117 13608	3982	10K00 5% 0,062W	4822 051 30103	5630	4,7UH/20%)	4822 157 10333
3812	4,7R 5% 0603 0,0016W	4822 117 13608	3984	47K 1% 0.063W 0603	4822 117 12925	5634	1UH/20%)	4822 157 11258
3814	4,7R 5% 0603 0,0016W	4822 117 13608	3986	47K 1% 0.063W 0603	4822 117 12925	5636	1UH/20%)	4822 157 11258
3816	4,7R 5% 0603 0,0016W	4822 117 13608	3988	RST NETW 4X4K7	2350 035 10472	5638	4,7UH/20%)	4822 157 10333
3818	15R 5% 0603 0,62W	4822 117 12971	3990	RST NETW 4X4K7	2350 035 10472	5640	BLM21A121SPT	4822 157 11506
3820	15R 5% 0603 0,62W	4822 117 12971	3991	6K80 5% 0,062W	4822 051 30682	5642	1UH/20%)	4822 157 11258
3822	1K00 5% 0,062W	4822 051 30102	3992	47R00 5% 0,062W	4822 051 30479	5644	BLM21A121SPT	4822 157 11506
3824	10K00 5% 0,062W	4822 051 30103	3993	33R00 5% 0,062W	4822 051 30339	5646	1UH/20%)	4822 157 11258
3826	100K 1% 0603 0.62W	4822 117 13632	Jumpers			5648	BLM21A601SPT	4822 157 71206
3844	100R00 5% 0,062W	4822 051 30101	4001	0R00 JUMPER	4822 051 30008	5650	BLM21A601SPT	4822 157 71206
3846	680K00 5% 0,062W	4822 051 30684	4003	0R00 JUMPER	4822 051 30008	5703	BLM21A601SPT	4822 157 71206
3848	100R00 5% 0,062W	4822 051 30101	4100	0R00 JUMPER	4822 051 30008	5705	BLM21A601SPT	4822 157 71206
3850	0R00 JUMPER	4822 051 30008	4501	0R00 JUMPER	4822 051 30008	5707	BLM21A601SPT	4822 157 71206
3854	1K00 5% 0,062W	4822 051 30102	4701	0R00 JUMPER	4822 051 30008	5800	BLM21A601SPT	4822 157 71206
3856	0R00 JUMPER	4822 051 30008	Coils & Transformers			5806	BLM21A601SPT	4822 157 71206
3860	100R00 5% 0,062W	4822 051 30101	5000	BLM21A601SPT	4822 157 71206	5808	BLM21A601SPT	4822 157 71206
3862	100R00 5% 0,062W	4822 051 30101	5002	BLM21A601SPT	4822 157 71206	5812	BLM21A601SPT	4822 157 71206
3864	3K9 5% 0.063W 0603	4822 051 30392	5004	BLM21A601SPT	4822 157 71206	5814	BLM21A601SPT	4822 157 71206
3866	3K30 5% 0,062W	4822 051 30332	5006	1210 22U PM10 R	2422 536 00164	5900	BLM21A601SPT	4822 157 71206
3868	1K00 5% 0,062W	4822 051 30102	5008	1210 22U PM10 R	2422 536 00164	5908	BLM21A601SPT	4822 157 71206
3870	1K00 5% 0,062W	4822 051 30102	5010	4,7UH/20%)	4822 157 10333	5912	4,7UH/20%)	4822 157 10333
3872	220K 1% ERJ3E	4822 117 12891	5106	BLM21A601SPT	4822 157 71206	5914	BLM21A601SPT	4822 157 71206
3874	220K 1% ERJ3E	4822 117 12891	5108	BLM21A601SPT	4822 157 71206	5916	BLM21A601SPT	4822 157 71206
3876	3K30 5% 0,062W	4822 051 30332	5110	BLM21A601SPT	4822 157 71206	5918	BLM21A601SPT	4822 157 71206
3878	100R00 5% 0,062W	4822 051 30101	5114	4,7UH/20%)	4822 157 10333	5920	BLM21A601SPT	4822 157 71206
3880	1K00 5% 0,062W	4822 051 30102	5116	BLM21A601SPT	4822 157 71206	5922	BLM21A601SPT	4822 157 71206
3882	100R00 5% 0,062W	4822 051 30101	5201	BLM21A601SPT	4822 157 71206	5924	BLM21A601SPT	4822 157 71206
3884	1K00 5% 0,062W	4822 051 30102	5202	BLM21A601SPT	4822 157 71206	5926	BLM21A601SPT	4822 157 71206
3886	220K 1% ERJ3E	4822 117 12891	5203	1UH/20%)	4822 157 11258	5928	BLM21A601SPT	4822 157 71206
3888	220K 1% ERJ3E	4822 117 12891	5205	BLM21A601SPT	4822 157 71206	5930	BLM21A601SPT	4822 157 71206
3890	100K 1% 0603 0.62W	4822 117 13632	5206	1UH/20%)	4822 157 11258	5932	BLM21A601SPT	4822 157 71206
3891	100K 1% 0603 0.62W	4822 117 13632	5207	BLM21A601SPT	4822 157 71206	5934	4,7UH/20%)	4822 157 10333
3892	100K 1% 0603 0.62W	4822 117 13632	5208	BLM21A121SPT	4822 157 11506	5936	BLM21A601SPT	4822 157 71206
3893	100K 1% 0603 0.62W	4822 117 13632	5209	BLM21A121SPT	4822 157 11506	5938	BLM21A601SPT	4822 157 71206
3894	10R00 5% 0,062W	4822 051 30109	5210	BLM21A121SPT	4822 157 11506	5940	BLM21A601SPT	4822 157 71206
3900	4K70 5% 0,062W	4822 051 30472				5942	BLM21A601SPT	4822 157 71206
3902	1K0 1% 0.063W 0603	5322 117 13018				5944	BLM21A601SPT	4822 157 71206
3906	4K7 1% 0.063W 0603	5322 117 13026				5946	BLM21A601SPT	4822 157 71206
3908	100R00 5% 0,062W	4822 051 30101				5948	4,7UH/20%)	4822 157 10333

5950	BLM21A601SPT	4822 157 71206
5952	BLM21A601SPT	4822 157 71206
5954	BLM21A601SPT	4822 157 71206
5955	EMI 100MHZ 550R R	2422 549 44222
5956	BLM21A601SPT	4822 157 71206
5959	BLM21A601SPT	4822 157 71206
5967	BLM21A601SPT	4822 157 71206
5969	BLM21A601SPT	4822 157 71206
5970	BLM21A601SPT	4822 157 71206

Diodes

6000	BZX284-C33	4822 130 11027
6002	BZX284-C33	4822 130 11027
6004	BZX284-C33	4822 130 11027
6006	BZX284-C33	4822 130 11027
6008	BZX284-C33	4822 130 11027
6010	BZX284-C33	4822 130 11027
6012	BAS216	9340 255 30135
6014	BAS216	9340 255 30135
6016	BZX284-C6V8	4822 130 10852
6018	BZX284-C6V8	4822 130 10852

6020	BZX284-C6V8	4822 130 10852
6022	BZX284-C6V8	4822 130 10852
6024	BZX284-C6V8	4822 130 10852
6026	MA701A	4822 130 81125
6100	TLMG3100	9322 085 77685
6300	BZX284-C33	4822 130 11027
6302	BZX284-C33	4822 130 11027
6304	BZX284-C33	4822 130 11027
6306	BZX284-C33	4822 130 11027
6308	BZX284-C33	4822 130 11027

6310	BZX284-C33	4822 130 11027
6312	BZX284-C33	4822 130 11027
6314	BZX284-C33	4822 130 11027
6316	BZX284-C33	4822 130 11027
6318	BZX284-C33	4822 130 11027
6320	BZX284-C33	4822 130 11027
6322	BZX284-C33	4822 130 11027
6402	TLMG3100	9322 085 77685
6403	TLMG3100	9322 085 77685
6600	BAT254	4822 130 10654

6602	MA701A	4822 130 81125
6700	BZX284-C6V8	4822 130 10852
6702	BZX284-C6V8	4822 130 10852
6704	BZX284-C6V8	4822 130 10852
6706	BZX284-C6V8	4822 130 10852
6800	BZX284-C6V8	4822 130 10852
6802	BZX284-C33	4822 130 11027
6804	BZX284-C33	4822 130 11027
6806	BZX284-C33	4822 130 11027
6808	BZX284-C33	4822 130 11027

6810	BZX284-C33	4822 130 11027
6812	BZX284-C33	4822 130 11027
6814	BZX284-C33	4822 130 11027
6816	BZX284-C33	4822 130 11027
6817	BZX284-C33	4822 130 11027

Transistors & IC's

7000	IC AD8183ARU	9322 165 01668
7002	BC847C	5322 130 42755
7004	BC846B	5322 130 60159
7006	BC846B	5322 130 60159
7008	BC847C	5322 130 42755

7010	74LVC126AD	9352 411 00118
7014	BC857C	5322 130 42756
7016	BC847C	5322 130 42755
7022	PC74HCT4538T	5322 209 11598
7024	BC846B	5322 130 60159
7030	ST24FC21M1	9322 149 41668
7034	IC LT1611CS5	9322 160 19685
7102	48MHZ 35P FXO-31 R	4822 242 10814
7108	PDIUSBH11AD	9352 589 10118
7116	LD1117D33	9322 116 74668

7200	LD1117D33	9322 116 74668
7201	LD1117D33	9322 116 74668
7202	IC AD9886KS-140	9322 173 89671
7300	LD1117D33	9322 116 74668
7304	IC SAA7118E/V1	9352 673 95518
7400	IC PW166-10TK	9322 174 22671
7501	ST24E16M6	4822 209 16954
7503	DS1708SESA	9322 149 40668
7510	prog.AM29LV800B-6231	3122 437 12400
7510	prog.AM29LV800B-7181	3122 437 12530

7511	CY62127VLL-70ZI	9322 154 50668
7600	74LVC126AD	9352 411 00118
7602	IC ICS307M-02T	9322 165 19668
7616	BSH111	9340 560 36235
7618	BSH111	9340 560 36235
7620	FS6377-01	9322 137 99668
7622	BSH111	9340 560 36235
7626	LT1507CS8	4822 209 17094
7628	LD1117D33	9322 116 74668
7630	LD1117D33	9322 116 74668

7708	BC847C	5322 130 42755
7711	BC847C	5322 130 42755
7712	BC847C	5322 130 42755
7715	IC 74LVC07AD	9352 654 81118
7719	CY6264-70SNC	4822 209 16439
7723	74HCT86N	5322 209 11473
7727	PROG. S87C654-4B44	3122 437 12410
7731	BC846B	5322 130 60159
7733	BC847C	5322 130 42755
7737	SN74HCT573DW	5322 209 31276

7802	TDA7433D	9322 149 66668
7804	TDA7056AT	9352 609 37118
7806	BSH111	9340 560 36235
7808	BSH111	9340 560 36235
7902	IC LD1117D	9322 157 39668
7904	PC74HCU04T	5322 209 11517
7906	PCF8574TS/F3	4822 209 13252
7908	BCP51	5322 130 62639
7910	IC LD1117D	9322 157 39668
7912	IC LD1117D	9322 157 39668

7914	TDA8444T/N4	5322 209 90559
7916	HEF4013BT	5322 209 14477
7918	IC LD1117D	9322 157 39668
7920	BC846B	5322 130 60159
7922	IC HEF4040BT	9333 728 50653
7946	BC847C	5322 130 42755

Drive Board**Connectors**

1101	SSB board BTB	2422 025 17278
1200	XTL 24M576 12P	2422 543 01115
1671	LCD 36 pins	2422 025 16967
1772	LCD 36 pins	2422 025 16967
1873	LCD 36 pins	2422 025 16967

Capacitors

2100	1206 6V3	10U PM10	2020 552 96672
2101	1210 16V	10U PM10	2020 552 96675
2103	0603 6V3	1U PM10	2020 552 96673
2200	0603 50V	100NP80M	2238 586 59812
2201	0603 50V	100NP80M	2238 586 59812
2202	0603 50V	100NP80M	2238 586 59812
2203	0603 50V	100NP80M	2238 586 59812
2204	0603 50V	100NP80M	2238 586 59812
2205	0603 50V	100NP80M	2238 586 59812
2206	0603 50V	100NP80M	2238 586 59812

2207	22PF 5%NP0	50V	4822 122 33761
2208	22PF 5%NP0	50V	4822 122 33761
2209	0603 50V	100NP80M	2238 586 59812
2212	0603 50V	100NP80M	2238 586 59812
2213	0603 50V	100NP80M	2238 586 59812
2214	0603 50V	100NP80M	2238 586 59812
2215	0603 50V	100NP80M	2238 586 59812
2300	0603 50V	100NP80M	2238 586 59812
2301	0603 50V	100NP80M	2238 586 59812
2302	0603 50V	100NP80M	2238 586 59812

2303	0603 50V	100NP80M	2238 586 59812
2304	0603 50V	100NP80M	2238 586 59812
2305	0603 50V	100NP80M	2238 586 59812
2306	0603 50V	100NP80M	2238 586 59812
2307	0603 6V3	1U PM10	2020 552 96673
2308	0603 50V	100NP80M	2238 586 59812
2309	0603 50V	100NP80M	2238 586 59812
2310	0603 50V	100NP80M	2238 586 59812
2311	0603 50V	100NP80M	2238 586 59812
2312	0603 6V3	1U PM10	2020 552 96673

2400	1206 16V	1U PM10	2020 552 95812
2401	0603 50V	100NP80M	2238 586 59812
2402	1206 16V	1U PM10	2020 552 95812
2403	1206 16V	1U PM10	2020 552 95812
2404	0603 NP0	50V 100P	2020 552 94427
2407	1206 16V	1U PM10	2020 552 95812
2408	0603 6V3	1U PM10	2020 552 96673
2409	0603 50V	100NP80M	2238 586 59812
2410	1206 6V3	10U PM10	2020 552 96672
2411	1206 6V3	10U PM10	2020 552 96672

2414	0603 50V	100NP80M	2238 586 59812
2415	0603 50V	100NP80M	2238 586 59812
2416	0603 50V	100NP80M	2238 586 59812
2417	0603 50V	100NP80M	2238 586 59812
2418	0603 50V	100NP80M	2238 586 59812
2419	0603 50V	100NP80M	2238 586 59812
2420	0603 50V	100NP80M	2238 586 59812
2500	0603 50V	100NP80M	2238 586 59812
2501	0603 50V	100NP80M	2238 586 59812
2502	0603 50V	100NP80M	2238 586 59812

2503	0603 50V	100NP80M	2238 586 59812
2504	0603 50V	100NP80M	2238 586 59812
2505	0603 50V	100NP80M	2238 586 59812
2506	1210 16V	10U PM10	2020 552 96675
2507	1206 6V3	10U PM10	2020 552 96672
2508	0603 50V	100NP80M	2238 586 59812
2509	0603 50V	100NP80M	2238 586 59812
2510	0603 50V	100NP80M	2238 586 59812
2511	0603 50V	100NP80M	2238 586 59812
2512	1210 16V	10U PM10	2020 552 96675

2517	0603 50V	100NP80M	2238 586 59812
2518	0603 50V	100NP80M	2238 586 59812
2519	0603 50V	100NP80M	2238 586 59812
2526	0603 50V	100NP80M	2238 586 59812

2527	0603 6V3	1U PM10	2020 552 96673	3210	NETW 4X4K7 PM6	2350 035 10472	3380	1R 5% 0,062W 0603	4822 117 12917
2528	0603 6V3	1U PM10	2020 552 96673	3212	NETW 4X10K	2350 035 10103	3381	1R 5% 0,062W 0603	4822 117 12917
2529	0603 50V 100NP80M		2238 586 59812	3216	1K00 5% 0,062W	4822 051 30102	3400	18K00 5% 0,062W	4822 051 30183
2530	0603 50V 100NP80M		2238 586 59812	3219	1K50 5% 0,062W	4822 051 30152	3401	2K20 5% 0,062W	4822 051 30222
2531	0603 6V3	1U PM10	2020 552 96673	3220	1K00 5% 0,062W	4822 051 30102	3402	3K30 5% 0,062W	4822 051 30332
2600	0603 50V 100NP80M		2238 586 59812	3221	820R 5% 0,62W	4822 117 12968	3403	3K30 5% 0,062W	4822 051 30332
2601	0603 50V 100NP80M		2238 586 59812	3222	NETW 4X10K	2350 035 10103	3404	22R 5% 0,062W	4822 117 12139
2602	0603 50V 100NP80M		2238 586 59812	3225	100R00 5% 0,062W	4822 051 30101	3405	22R 5% 0,062W	4822 117 12139
2603	0603 50V 100NP80M		2238 586 59812	3228	NETW 4X10K	2350 035 10103	3406	1K00 5% 0,062W	4822 051 30102
2604	0603 50V 100NP80M		2238 586 59812	3234	1K00 5% 0,062W	4822 051 30102	3407	100R00 5% 0,062W	4822 051 30101
				3236	47R00 5% 0,062W	4822 051 30479	3408	100R00 5% 0,062W	4822 051 30101
2605	0603 50V 100NP80M		2238 586 59812	3240	10K00 5% 0,062W	4822 051 30103	3409	3K9 5% 0.063W 0603	4822 051 30392
2606	1210 16V	10U PM10	2020 552 96675	3241	10K00 5% 0,062W	4822 051 30103	3410	330R00 5% 0,062W	4822 051 30331
2607	1206 6V3	10U PM10	2020 552 96672	3242	100R00 5% 0,062W	4822 051 30101	3411	2K20 5% 0,062W	4822 051 30222
2608	0603 50V 100NP80M		2238 586 59812	3243	100R00 5% 0,062W	4822 051 30101	3412	150R00 5% 0,062W	4822 051 30151
2609	0603 50V 100NP80M		2238 586 59812	3248	1K00 5% 0,062W	4822 051 30102	3413	1K00 5% 0,062W	4822 051 30102
2610	0603 50V 100NP80M		2238 586 59812	3250	47R00 5% 0,062W	4822 051 30479	3414	2R2 5% 0603	4822 117 13613
2611	0603 50V 100NP80M		2238 586 59812	3251	1K00 5% 0,062W	4822 051 30102	3415	1K00 5% 0,062W	4822 051 30102
2612	1210 16V	10U PM10	2020 552 96675	3252	100R00 5% 0,062W	4822 051 30101	3416	100R00 5% 0,062W	4822 051 30101
2617	0603 50V 100NP80M		2238 586 59812	3253	100R00 5% 0,062W	4822 051 30101	3417	100R00 5% 0,062W	4822 051 30101
2618	0603 50V 100NP80M		2238 586 59812						
				3254	100R00 5% 0,062W	4822 051 30101	3418	330R00 5% 0,062W	4822 051 30331
2619	0603 50V 100NP80M		2238 586 59812	3255	10K00 5% 0,062W	4822 051 30103	3420	NETW 4X 27K	2350 035 10273
2626	0603 50V 100NP80M		2238 586 59812	3256	10K00 5% 0,062W	4822 051 30103	3423	NETW 4X3K3 PM5	2350 035 10332
2627	0603 6V3	1U PM10	2020 552 96673	3257	3K30 5% 0,062W	4822 051 30332	3426	3K30 5% 0,062W	4822 051 30332
2628	0603 6V3	1U PM10	2020 552 96673	3260	47R00 5% 0,062W	4822 051 30479	3427	NETW 4X10K	2350 035 10103
2629	0603 50V 100NP80M		2238 586 59812	3261	47R00 5% 0,062W	4822 051 30479	3430	NETW 4X3K3 PM6	2350 035 10332
2630	0603 50V 100NP80M		2238 586 59812	3262	47R00 5% 0,062W	4822 051 30479	3438	NETW 4X10K	2350 035 10103
2631	0603 6V3	1U PM10	2020 552 96673	3263	10K00 5% 0,062W	4822 051 30103	3442	1K00 5% 0,062W	4822 051 30102
2632	0603 6V3	1U PM10	2020 552 96673	3264	10K00 5% 0,062W	4822 051 30103	3443	6K80 5% 0,062W	4822 051 30682
2700	0603 50V 100NP80M		2238 586 59812	3267	1K00 5% 0,062W	4822 051 30102	3444	4K70 5% 0,062W	4822 051 30472
2701	0603 50V 100NP80M		2238 586 59812						
				3268	1K00 5% 0,062W	4822 051 30102	3445	4K70 5% 0,062W	4822 051 30472
2702	0603 50V 100NP80M		2238 586 59812	3300	NETW 4X47R	2350 035 10479	3446	4K70 5% 0,062W	4822 051 30472
2703	0603 50V 100NP80M		2238 586 59812	3302	NETW 4X47R	2350 035 10479	3447	3K30 5% 0,062W	4822 051 30332
2704	0603 50V 100NP80M		2238 586 59812	3304	47R00 5% 0,062W	4822 051 30479	3448	680R 5% 0,062W	4822 051 30681
2705	0603 50V 100NP80M		2238 586 59812	3309	47R00 5% 0,062W	4822 051 30479	3501	47K 1% 0.063W 0603	4822 117 12925
2706	1210 16V	10U PM10	2020 552 96675	3310	47R00 5% 0,062W	4822 051 30479	3506	1K00 5% 0,062W	4822 051 30102
2707	1206 6V3	10U PM10	2020 552 96672	3311	47R00 5% 0,062W	4822 051 30479	3507	2K20 5% 0,062W	4822 051 30222
2708	0603 50V 100NP80M		2238 586 59812	3315	NETW 4X47R	2350 035 10479	3509	100R00 5% 0,062W	4822 051 30101
2709	0603 50V 100NP80M		2238 586 59812	3319	NETW 4X47R	2350 035 10479	3510	R2 5% 0603	4822 117 13613
2710	0603 50V 100NP80M		2238 586 59812	3320	47R00 5% 0,062W	4822 051 30479	3511	100R00 5% 0,062W	4822 051 30101
2711	0603 50V 100NP80M		2238 586 59812						
				3321	47R00 5% 0,062W	4822 051 30479	3512	2R2 5% 0603	4822 117 13613
2712	1210 16V	10U PM10	2020 552 96675	3325	NETW 4X47R	2350 035 10479	3513	2K20 5% 0,062W	4822 051 30222
2717	0603 50V 100NP80M		2238 586 59812	3329	NETW 4X47R	2350 035 10479	3514	22R 5% 0,062W	4822 117 12139
2718	0603 50V 100NP80M		2238 586 59812	3330	NETW 4X47R	2350 035 10479	3515	1K00 5% 0,062W	4822 051 30102
2719	0603 50V 100NP80M		2238 586 59812	3332	NETW 4X47R	2350 035 10479	3516	22R 5% 0,062W	4822 117 12139
2726	0603 50V 100NP80M		2238 586 59812	3340	47R00 5% 0,062W	4822 051 30479	3517	1K00 5% 0,062W	4822 051 30102
2727	0603 6V3	1U PM10	2020 552 96673	3341	NETW 4X47R	2350 035 10479	3601	47K 1% 0.063W 0603	4822 117 12925
2728	0603 6V3	1U PM10	2020 552 96673	3342	47R00 5% 0,062W	4822 051 30479	3606	1K00 5% 0,062W	4822 051 30102
2729	0603 50V 100NP80M		2238 586 59812	3343	NETW 4X47R	2350 035 10479	3607	2K20 5% 0,062W	4822 051 30222
2730	0603 50V 100NP80M		2238 586 59812	3347	47R00 5% 0,062W	4822 051 30479	3609	100R00 5% 0,062W	4822 051 30101
2731	0603 6V3	1U PM10	2020 552 96673						
2732	0603 6V3	1U PM10	2020 552 96673	3348	47R00 5% 0,062W	4822 051 30479	3610	2R2 5% 0603	4822 117 13613
				3349	NETW 4X47R	2350 035 10479	3611	100R00 5% 0,062W	4822 051 30101
				3354	NETW 4X47R	2350 035 10479	3612	2R2 5% 0603	4822 117 13613
				3357	47R00 5% 0,062W	4822 051 30479	3613	2K20 5% 0,062W	4822 051 30222
				3358	NETW 4X47R	2350 035 10479	3614	22R 5% 0,062W	4822 117 12139
				3362	NETW 4X47R	2350 035 10479	3615	1K00 5% 0,062W	4822 051 30102
				3363	47R00 5% 0,062W	4822 051 30479	3616	22R 5% 0,062W	4822 117 12139
				3367	47R00 5% 0,062W	4822 051 30479	3617	1K00 5% 0,062W	4822 051 30102
				3368	NETW 4X47R	2350 035 10479	3701	47K 1% 0.063W 0603	4822 117 12925
				3370	4K70 5% 0,062W	4822 051 30472	3706	1K00 5% 0,062W	4822 051 30102
				3375	47R00 5% 0,062W	4822 051 30479	3707	2K20 5% 0,062W	4822 051 30222
				3376	4K70 5% 0,062W	4822 051 30472	3709	100R00 5% 0,062W	4822 051 30101
				3377	4K70 5% 0,062W	4822 051 30472	3710	2R2 5% 0603	4822 117 13613
				3378	4K70 5% 0,062W	4822 051 30472	3711	100R00 5% 0,062W	4822 051 30101
				3379	1R 5% 0,062W 0603	4822 117 12917	3712	2R2 5% 0603	4822 117 13613

Resistors

3101	10K00 5% 0,062W	4822 051 30103
3102	10K00 5% 0,062W	4822 051 30103
3200	1K00 5% 0,062W	4822 051 30102
3201	4K70 5% 0,062W	4822 051 30472
3202	4K70 5% 0,062W	4822 051 30472
3203	4K70 5% 0,062W	4822 051 30472
3204	4K70 5% 0,062W	4822 051 30472
3205	NETW 4X4K7 PM5	2350 035 10472
3206	100R00 5% 0,062W	4822 051 30101
3207	10K00 5% 0,062W	4822 051 30103

3713	2K20 5% 0,062W	4822 051 30222
3714	22R 5% 0,062W	4822 117 12139
3715	1K00 5% 0,062W	4822 051 30102
3716	22R 5% 0,062W	4822 117 12139
3717	1K00 5% 0,062W	4822 051 30102

Coils

5100	-4R7M (4,7UH/20%)	4822 157 10333
5101	-4R7M (4,7UH/20%)	4822 157 10333
5200	BLM21A601SPT	4822 157 71206
5201	BLM21A601SPT	4822 157 71206
5202	BLM21A601SPT	4822 157 71206
5203	BLM21A601SPT	4822 157 71206
5204	BLM21A601SPT	4822 157 71206
5205	BLM21A601SPT	4822 157 71206
5206	BLM21A601SPT	4822 157 71206
5207	BLM21A601SPT	4822 157 71206

5208	BLM21A601SPT	4822 157 71206
5300	BLM21A601SPT	4822 157 71206
5301	BLM21A601SPT	4822 157 71206
5302	BLM21A601SPT	4822 157 71206
5400	BLM21A601SPT	4822 157 71206
5401	BLM21A601SPT	4822 157 71206
5402	BLM21A601SPT	4822 157 71206
5403	BLM21A601SPT	4822 157 71206
5500	BLM21A601SPT	4822 157 71206
5501	BLM21A601SPT	4822 157 71206

5502	BLM21A601SPT	4822 157 71206
5503	BLM21A601SPT	4822 157 71206
5504	BLM21A601SPT	4822 157 71206
5507	BLM21A601SPT	4822 157 71206
5508	BLM21A601SPT	4822 157 71206
5509	BLM21A601SPT	4822 157 71206
5600	BLM21A601SPT	4822 157 71206
5601	BLM21A601SPT	4822 157 71206
5602	BLM21A601SPT	4822 157 71206
5603	BLM21A601SPT	4822 157 71206

5604	BLM21A601SPT	4822 157 71206
5607	BLM21A601SPT	4822 157 71206
5608	BLM21A601SPT	4822 157 71206
5609	BLM21A601SPT	4822 157 71206
5700	BLM21A601SPT	4822 157 71206
5701	BLM21A601SPT	4822 157 71206
5702	BLM21A601SPT	4822 157 71206
5703	BLM21A601SPT	4822 157 71206
5704	BLM21A601SPT	4822 157 71206
5707	BLM21A601SPT	4822 157 71206

5708	BLM21A601SPT	4822 157 71206
5709	BLM21A601SPT	4822 157 71206

Diodes

6200	BAT54	4822 130 80622
6201	BZX284-C2V7	4822 130 10756
6401	BZX84-A12 (PHSE) R	9340 117 70215

Transistors & IC's

7200	IC DS1815R-10	9322 158 94685
7201	BSH111	9340 560 36235
7202	BSH111	9340 560 36235
7203	IC 74LVC573AD	9352 190 00118
7206	TMP91CW12AF-9999	9322 170 75671
7208	IC SM 74AHCT1G08GW	9352 627 54115
7209	IC SM 74AHCT1G08GW	9352 627 54115
7210	74LVC04AD	4822 209 16399
7211	DTA124EU-W	4822 130 60854
7212	DTC124EU	4822 130 61553

7213	74LVC86AD	4822 209 17463
7300	IC SM L3E07050K0B	9322 188 06702
7400	BC846B	5322 130 60159
7401	LM358D	5322 209 82941
7402	BCP56	5322 130 63033
7403	TL431ACD	4822 209 16406
7405	IC M24128-BWMN6	9322 152 35668
7406	TL431ACD	4822 209 16406
7407	MC78L05ACD	4822 209 33411
7408	TDA8444T/N4	5322 209 90559

7410	IC SM LT1763CS8	9322 151 49668
7411	BC846B	5322 130 60159
7504	IC SM L3E01040F0A	9322 184 10671
7505	IC SM L3E06070D0A	9322 174 62671
7506	TRA SIG BC847BPN	9340 425 30115
7508	TRA SIG BC847BPN	9340 425 30115
7510	LM358D	5322 209 82941
7604	IC SM L3E01040F0A	9322 184 10671
7605	IC SM L3E06070D0A	9322 174 62671
7606	TRA SIG BC847BPN	9340 425 30115

7608	TRA SIG BC847BPN	9340 425 30115
7610	LM358D	5322 209 82941
7704	IC SM L3E01040F0A	9322 184 10671
7705	IC SM L3E06070D0A	9322 174 62671
7706	TRA SIG BC847BPN	9340 425 30115
7708	TRA SIG BC847BPN	9340 425 30115
7710	LM358D	5322 209 82941

Test points

9200	Test device	4822 404 60717
9201	Test device	4822 404 60717
9510	Test device	4822 404 60717
9610	Test device	4822 404 60717
9710	Test device	4822 404 60717

Keyboard

Connectors

1020	15P F 1.00 FFC 0.3 R	2422 025 16919
1021	4P F 1.00 FFC 0.3 B	2422 025 16979

Capacitors

2000	100NF 10% 0805 50V	4822 126 14585
2001	100NF 10% 0805 50V	4822 126 14585

Resistors

3000	100R00 5% 0,062W	4822 051 30101
3001	100R00 5% 0,062W	4822 051 30101
3002	330R00 5% 0,062W	4822 051 30331
3005	330R00 5% 0,062W	4822 051 30331
3006	68R 5% 0,063W 0603	4822 051 30689
3007	100R00 5% 0,062W	4822 051 30101
3008	100R00 5% 0,062W	4822 051 30101
3009	22K00 5% 0,062W	4822 051 30223
3010	22K00 5% 0,062W	4822 051 30223
3011	22K00 5% 0,062W	4822 051 30223

3012	330R00 5% 0,062W	4822 051 30331
3013	22K00 5% 0,062W	4822 051 30223
3014	22K00 5% 0,062W	4822 051 30223
3015	68R 5% 0,063W 0603	4822 051 30689
3016	22K00 5% 0,062W	4822 051 30223
3017	330R00 5% 0,062W	4822 051 30331
3018	68R 5% 0,063W 0603	4822 051 30689

Coils

5000	BLM21A601SPT	4822 157 71206
5001	BLM21A601SPT	4822 157 71206

Diodes & LED's

6000	TLMV3100	4822 130 83915
6001	TLMV3100	4822 130 83915
6002	TLMV3100	4822 130 83915
6003	TLMH3100	4822 130 11395

Transistors & IC's

7000	DS1621V	4822 209 16906
7001	BC856B	4822 130 60373
7003	BC856B	4822 130 60373
7004	PCF8574T	5322 209 11578
7005	BC856B	4822 130 60373
7006	BC856B	4822 130 60373
7007	BC856B	4822 130 60373
7008	BC856B	4822 130 60373

Jumpers

9010	0R00 JUMP. (0805)	4822 051 20008
9011	0R00 JUMP. (0805)	4822 051 20008

IR-board

Connectors

1000	4P F 1.00 FFC 0.3 B	2422 025 16979
------	---------------------	----------------

Capacitors

2000	TANCAP6V3 47U	2020 004 90266
------	---------------	----------------

Resistors

3000	47R00 5% 0,062W	4822 051 30479
------	-----------------	----------------

IR-receiver

7000	I.R.Receiver TSOP2136	3122 438 70920
------	-----------------------	----------------